

IC655BEM510

New In Stock!

GE Fanuc

<http://www.pdfsupply.com/automation/ge-fanuc/ge-series-five-5/IC655BEM510>

Ge Series Five 5

1-919-535-3180

**In Stock! GE Genius Bus Controller -32 devices IC655B IC655BE
IC655BEM**

www.pdfsupply.com

Email: sales@pdfsupply.com

GFK-0248

New In Stock!

~~GE Fanuc Manuals~~

[http://www.pdfsupply.com/automation/ge-fanuc-manuals/series-five-](http://www.pdfsupply.com/automation/ge-fanuc-manuals/series-five-ic655/GFK-0248)

[ic655/GFK-0248](http://www.pdfsupply.com/automation/ge-fanuc-manuals/series-five-ic655/GFK-0248)
series-five-ic655

1-919-535-3180

**Series Five Programmable Controller Genius Bus Controller User's
Manual**

www.pdfsupply.com

Email: sales@pdfsupply.com



GE Fanuc Automation

Programmable Control Products

Series Five[™] Programmable Controller Genius Bus Controller

User's Manual

GFK-0248A

October, 1990

Warnings, Cautions, and Notes as Used in this Publication

Warning

Warning notices are used in this publication to emphasize that hazardous voltages, currents, temperatures, or other conditions that could cause personal injury exist in this equipment or may be associated with its use.

In situations where inattention could cause either personal injury or damage to equipment, a Warning notice is used.

Caution

Caution notices are used where equipment might be damaged if care is not taken.

Note

Notes merely call attention to information that is especially significant to understanding and operating the equipment.

This document is based on information available at the time of its publication. While efforts have been made to be accurate, the information contained herein does not purport to cover all details or variations in hardware or software, nor to provide for every possible contingency in connection with installation, operation, or maintenance. Features may be described herein which are not present in all hardware and software systems. GE Fanuc Automation assumes no obligation of notice to holders of this document with respect to changes subsequently made.

GE Fanuc Automation makes no representation or warranty, expressed, implied, or statutory with respect to, and assumes no responsibility for the accuracy, completeness, sufficiency, or usefulness of the information contained herein. No warranties of merchantability or fitness for purpose shall apply.

The following are trademarks of GE Fanuc Automation North America, Inc.

Alarm Master	Field Control	Modelmaster	Series One
CIMPLICITY	GENet	PowerMotion	Series Six
CIMPLICITY Control	Genius	ProLoop	Series Three
CIMPLICITY PowerTRAC	Genius PowerTRAC	PROMACRO	VuMaster
CIMPLICITY 90-ADS	Helpmate	Series Five	Workmaster
CIMSTAR	Logicmaster	Series 90	

GFK-0248

The Bus Controller for the Series Five Programmable Logic Controller (PLC) is the required interface between a Series Five™ PLC and a Genius™ I/O network. This manual describes the functions of the Bus Controller and how it interfaces the Genius I/O system to the Series Five Programmable Logic Controller. The factory set default configuration for the Bus Controller allows you to have your system up and running in a minimum of time.

Content of This Manual

- Chapter 1. Introduction:** This chapter provides an overview of the features and functions of the Bus Controller for the Series Five Programmable Logic Controller. Included is a discussion of the factory defaults that should satisfy the application requirements for many users with no further configuration of the Bus Controller.
- Chapter 2. The Genius Network:** This chapter describes the Genius network as used with the Series Five PLC. This includes Series Five PLC compatibility with Genius I/O blocks, and CPU to CPU communications through a Global communications network.
- Chapter 3. Installation and Setup:** This chapter describes the installation and setup procedures required to use a Series Five Genius Bus Controller in your Series Five PLC system.
- Chapter 4. Operation with RD/WR CCM Devices:** This chapter describes how to use the Read CCM and Write CCM instructions in a Series Five PLC Genius network to communicate with other Series Five PLC systems with Genius I/O Bus Controllers.
- Chapter 5. Troubleshooting:** This chapter provides basic troubleshooting information to help you to quickly solve any problems which may occur with operation of the Bus Controller
- Appendix A. Diagnostic Information:** This Appendix provides information about the Genius I/O diagnostics, including information on construction and contents of the fault table. It also describes fault reporting functions. Default Genius I/O Diagnostics are described with the contents of the default registers listed for your information.
- Appendix B. Scratch Pad Memory Map for Genius Bus Controller Setup Parameters:** Definitions of Genius Bus Controller setup parameters and their location in Scratch Pad memory are listed in this Appendix.
- Appendix C. Datagram Transmission between Series Five and Series Six PLCs:** Provides an example of using the TRANSFER instruction for datagram transmission between Series Five and Series Six PLCs.
- Appendix D. Switch BSM Datagram Command From a Series Five PLC:** Provides an example of sending a BSM switch command from a Series Five PLC.
- Appendix E. Setup Differences Based on CPU Revisions:** Describes differences in setup procedures depending on the revision level of the Series Five CPU.

Related Publications

- GFK-0122 - Series Five™ Programmable Controller User's Manual
- GFK-0023 - Logicmaster™ 5 Programming and Documentation Software User's manual
- GFK-0181 - Series Five™ Operator Interface Unit User's Manual
- GFK-0171 - Series Six™ Bus Controller User's Manual
- GEK-90486 - Genius™ I/O System User's Manual

At GE Fanuc Automation, we strive to produce quality technical documentation. After you have used this manual, please take a few moments to complete and return the Reader's Comment Card located on the next page.

Henry A. Konat
Senior Technical Writer

READER'S COMMENTS

We invite your comments and welcome suggestions to make this manual more useful.

Publication No. _____ Date of Publication _____ Today's Date _____

GENERAL COMMENTS:

	Improve	Acceptable	Good	Excellent
Contents	☐	☐	☐	☐
Organization	☐	☐	☐	☐
Accuracy	☐	☐	☐	☐
Clarity	☐	☐	☐	☐
Completeness	☐	☐	☐	☐
Examples/Illustrations	☐	☐	☐	☐
Referencing/Indexing	☐	☐	☐	☐
Readability	☐	☐	☐	☐

DETAILED COMMENTS: (Correct, expand, etc. – Please be specific.)

Page No. Comment

_____	_____
_____	_____
_____	_____
_____	_____

Other suggestions for improving this document: _____

As compared to other manufacturers of a similar product, how would you rate this document ?

Superior ☐ Comparable ☐ Inferior ☐ Don't Know ☐

Comments: _____

Are you interested in subscribing to a documentation update plan? Yes ☐ No ☐

APPLICATION INFORMATION:

Indicate the type of user/reader function that you most nearly represent:

- | | |
|--|---|
| ☐ System Designer | ☐ Programmer |
| ☐ Distributor | ☐ Maintenance |
| ☐ OEM | ☐ Operator |
| ☐ Installation | ☐ Other (Please Specify) _____ |

Type of Equipment: ☐ Series 90-70 ☐ Series 90-30 ☐ Series 90-20 ☐ Series Six
 ☐ Series Five ☐ Series One ☐ Genius I/O ☐ Other _____

Comments concerning your specific application: _____

CUT ON DOTTED LINE



From:

Name: _____

Title: _____

Company: _____

Address: _____

City/State/Zip: _____

Telephone: _____

Fold Here



No Postage
Necessary
If Mailed
In The
United States

BUSINESS REPLY MAIL

FIRST CLASS MAIL PERMIT NO. 995 CHARLOTTESVILLE, VA

POSTAGE WILL BE PAID BY ADDRESSEE:

ATTENTION MANAGER TECHNICAL PUBLICATIONS
GE Fanuc Automation North America Inc
P O BOX 8106
CHARLOTTESVILLE VA 22907-6063



Fold Here

CHAPTER 1.	INTRODUCTION	
	Product Summary	1-1
	Using Genius I/O with a Series Five PLC	1-1
	Purpose of the Genius Bus Controller	1-2
	Bus Controller Description	1-2
	LEDs	1-3
	Bus Controller Specifications	1-4
CHAPTER 2.	THE GENIUS NETWORK	
	Introduction	2-1
	Genius I/O Serial Bus	2-1
	The Bus Scan	2-2
	Typical Genius I/O Bus	2-2
	Interfacing With Genius Networks	2-3
	The Serial Bus Address	2-3
	Starting Reference Address	2-3
	Supporting Genius Communications Between CPUs	2-4
	Datagrams	2-4
	Global Data Communications	2-5
	Combining Global Data Communications and I/O Control	2-5
	Redundancy	2-5
	Dual Bus Redundancy	2-5
	Dual Controller Redundancy	2-6
CHAPTER 3.	INSTALLATION AND SETUP	
	Bus Controller Location in a System	3-1
	Bus Controller Installation and Configuration	3-1
	Selection of Serial Bus Address	3-2
	Selection of Serial Bus Baud Rate	3-2
	Setting the Outputs Enable DIP Switch	3-3
	Using a Bus Controller with Default Setup Conditions	3-3
	Installing the Bus Controller	3-3
	Configuration with Logicmaster 5	3-4
	Operation with Genius I/O Blocks	3-4
	Genius I/O Block Setup Procedures	3-5
	Enabling and Changing Global Data Values	3-8
	Changing the Global Data Setup	3-8
	Configuration Parameters for Global Data Communications	3-9
	Entering GBC Setup Parameters With the OIU	3-9
	Editing GBC Setup Parameters With Logicmaster 5 Software	3-9
	Displaying the Bus Controller Setup Screen	3-9
	Bus Controller Setup Key Summary	3-10
	Setup Ranges	3-10
	Reference Address	3-11
	Global Data and Transmit Data Lengths	3-11
	General System Information	3-12
	Series Five CPU Scratchpad Genius Definitions	3-13

CHAPTER 4.	OPERATION WITH RD/WR CCM INSTRUCTIONS	
	Introduction	4-1
	Use of Read CCM and Write CCM to Communicate with Other CPUs	4-1
	Read/Write CCM	4-2
	Example of Reading from a Remote CPU:	4-3
	Example of Writing to a Remote Series Five PLC with a Genius Bus Controller:	4-3
CHAPTER 5.	OPERATION WITH GENIUS I/O DIAGNOSTICS	
	Introduction	5-1
	User Interface to Genius I/O Diagnostics	5-1
	Displaying the Genius I/O Diagnostics Screen	5-1
	Fault Table Display	5-2
	Contents of Fault Table	5-2
	Special Registers, Contacts, and Coils for Genius I/O	
	Operation	5-2
	Special Registers	5-3
	Internal Coils	5-4
	Clear All Faults and Pulse Test Function	5-5
	Device Loss	5-6
	Device Addition	5-6
	Address Conflict	5-6
	Internal Contacts	5-7
CHAPTER 6.	TROUBLESHOOTING	
	How to Begin	6-1
	Identifying the Problem	6-1
APPENDIX A.	Diagnostic Information	A-1
	Bus Controller Diagnostic Information	A-1
	Default Genius I/O Diagnostic Fault Configuration	A-1
	Registers for Default Configuration	A-2
	Data Entered in Fault Tables	A-2
APPENDIX B.	Scratch Pad Memory Map for Genius Bus Controller Setup Parameters	B-1
APPENDIX C.	Datagram Transmission Between Series Five and Series Six PLCs	C-1
	Datagram Format	C-2
	The TRANSFER Command	C-3
	Sending Datagrams - Series Five PLC to Series Six PLC	C-4
	Relay Ladder Diagram Example	C-8
APPENDIX D.	Switch BSM Datagram Command From a Series Five PLC	D-1
APPENDIX E.	Setup Differences Based on CPU Revisions	E-1
	Compatibilities	E-1
	Restrictions	E-1
	Differences in Operation Between CPU Revision B and Later Revision CPUs	E-2

GFK-0248

Figure	1-1	Example of Bus Controller Interface to Genius I/O	1-2
	1-2	Bus Controller for the Series Five PLC	1-3
	2-1	Typical Genius Network for I/O Control	2-1
	2-2	Genius I/O Serial Bus Token Passing	2-2
	2-3	Genius I/O Serial Bus Scan	2-2
	2-4	Genius Network for CPU to CPU Communications	2-4
	3-1	Bus Controller Installation in a CPU Base Unit	3-4

GFK-0248

Table	3-1	Genius I/O Reference Address Assignment	3-5
	3-2	Valid Bus Controller Setup Ranges	3-10
	3-3	Global Data And Transmit Data Lengths	3-11
	3-4	Datagram Mapping	3-12
	3-5	Genius Information in CPU Scratchpad	3-13
	4-1	CCM/CPU Mapping	4-1
	5-1	Registers for Genius I/O Diagnostics	5-3
	5-2	Internal Coils for Genius I/O Diagnostics	5-4

Product Summary

This manual describes the Bus Controller (catalog number IC655BEM510) for the GE Fanuc Series Five™ Programmable Logic Controller (PLC). The Bus Controller is the Series Five PLC link to a Genius™ I/O system communications network. The following capabilities are available through the use of the Genius network with the Series Five PLC.

- Compatibility with GE Fanuc Genius I/O blocks including discrete, analog, high speed counter, and PowerTRAC.
- Communications between Series Five PLCs (via RD CCM and WR CCM instructions). This allows general purpose communications between up to 32 Series Five PLCs at a low priority level.
- Global data sharing with up to 31 other Series Five CPUs, and other compatible GE Fanuc products. This allows high priority data to be transmitted automatically to other devices on the bus.
- General purpose low priority communications with other devices which support Genius datagrams.
- Redundant CPU configurations. Refer to GE Fanuc Application Notes for examples of redundancy.

Genius I/O blocks are configured using the Genius I/O Hand-Held Monitor (HHM), and the global communications configuration requires only setting the Serial Bus Address (SBA), global data location, and data transmit length for each Bus Controller. The HHM must be catalog number IC660HHM501C, version 3.0, or later for use with a Series Five PLC system. This version of the HHM allows you to select the Series Five PLC for HHM operations.

Genius system setup may be done with Logicmaster 5 or the Series Five Operator Interface Unit (OIU). It is possible to use any of the I1+, I2+, O1+, or O2+ tables, or registers for Genius I/O blocks, or for CPU to CPU data transfers. Additionally, communications with GE Fanuc Series Six PLCs and other GE Fanuc devices is possible through the global communications setup.

For more information on the Genius I/O system operation, and setup, refer to the following manuals:

- GEK-90486 - Genius™ I/O System User's Manual
- GFK-0171 - Series Six™ Bus Controller User's Manual
- GFK-0023 - Logicmaster™ 5 Programming and Documentation Software User's Manual
- GFK-0181 - Series Five™ Operator Interface Unit User's manual

Included in this chapter is an introduction to the Bus Controller for the Series Five PLC, its purpose in the system, a physical description of the Bus Controller, including specifications, and configuration and installation requirements.

Using Genius I/O with a Series Five PLC

Genius I/O phase A products cannot be used in a Series Five PLC system where any of the following features are used: Global data, Datagrams (including RD CCM /WR CCM instructions used with the Bus Controller), baud rates other than 153.6K baud (standard), redundancy, or multiple controllers on the same bus. To program Genius I/O blocks in the I2+ and O2+ tables, and in the register tables, you must have version 3.0 of the Genius I/O Hand-Held Monitor. Genius I/O phase B products allow use of the above features.

Systems which use phase A blocks are limited to a single Series Five CPU and Bus Controller connected to Genius I/O blocks. This is not a restriction when using phase B blocks.

Purpose of the Genius Bus Controller

The Bus Controller functions as the interface between the Series Five PLC and the Genius I/O serial bus. A Bus Controller provides a variety of communications capabilities on the network. The purpose of the network determines which of those capabilities are used. If the network consists of only standard I/O control, the Genius communications network automatically provides communications between devices on the bus. In this instance, no special ladder logic programming is required.

If Global communications is to be a feature of the network, you must specify Genius Bus Controller reference address and Global Data Length through either LogiMaster 5 software or the Series Five Operator Interface Unit.




Figure 1-1. Example of Bus Controller Interface to Genius I/O

Bus Controller Description

A Bus Controller for the Series Five PLC is a single module consisting of a daughter board and mother board. The Bus Controller plugs into a single I/O slot in a Series Five CPU base unit. There is one DIP (Dual-In-Line) switch pack, consisting of 8 switches, requiring configuration by the user at installation (if the factory default configuration is not sufficient for your application). Two LEDs on the top front of the module provide a visual indication of the health of the module, and status of the communications link.

The front of the module has a terminal block with four screw connections which provide the connecting link to the Genius I/O serial bus. This group of connections is also provided on all Genius I/O blocks. A 9-pin connector provides a connection to the serial bus for the Genius I/O Hand-Held Monitor (HHM).

GFK-0248




Figure 1-2. Bus Controller for the Series Five PLC

LEDs

The two LEDs on the front of the Genius Bus Controller module provide a visual indication of its operating status. Both LEDs should be on during normal operation.

- **BD OK** Shows the status of the Genius Bus Controller. This LED blinks during powerup diagnostics.
- **COMM OK** Shows the status of the Genius serial bus. This LED is on steadily when the bus is operating properly. It blinks for intermittent bus errors and is off for a failed bus. It is also off when no configuration has been received from the CPU.

For more detailed information on troubleshooting with the LEDs, refer to Chapter 7 in this manual.

Bus Controller Specifications

Specifications for the Bus Controller and Genius I/O network are given in the following table.

Operational: Power Requirements Size Weight LEDs Number of Devices on Bus Bus Type Isolation Baud Rates Bus Scan Time Communications Environmental: Operating Temperature Storage Temperature Humidity Atmosphere Vibration Shock Radio Frequency Interference Genius Network: Modulation Technique Data Encoding Isolation Signal/Noise Ratio Cable Network Topology Termination Error Checking Network Access	500 ma at +5 V dc, from Series Five PLC power supply 9.8" (250mm) H x 1.8" (45mm) W x 5.1" (129mm) D 1.8 lbs (815 grams) BD OK (Board OK), COMM OK (Communications OK) Up to 32 Shielded, twisted pair cable or Twinax 1500 volts between devices on the bus 153.6K baud standard, 153.6K baud extended, 76.8K baud, 38.4K baud 3 ms minimum, 10 ms typical, 400 ms maximum (actual bus scan time can be observed in CPU registers 4041 through 4048). Transmit Global Data from I/O or registers for peer-to-peer communications. Receive Directed Data from other CPUs on the network. Transmit and Receive Datagrams. 0°C to +60°C (32°F to 140°F) -20°C to +70°C (-4°F to 158°F) 5% to 95% (non-condensing) No corrosive gases Mil-std 810C method 514.2, Rank (F) Mil-std 810C method 516.2 FCC Class A, part 15, subpart J FSK, 0/460.8 Khz (maximum), (153.6K baud) Each bit is encoded into three dipulses, majority voted at the receiver to correct any single dipulse errors. A dipulse is an AC code consisting of a positive then negative excursion of voltage. Dipulses are individually sampled to reject low and high frequency interference. 2000 volts Hi-pot, 1500 volts transient common mode rejection 60 db Single twisted pair plus shield or Twinax. Length up to 2000 feet (606) meters at 153.6K baud standard, up to 7500 feet (2280) meters at 38.4K baud - depending on type of cable used. Daisy-chained bus Matched resistance at both ends of bus (75/150 ohms). CRC check for each message Token passing with implicit token and fast token recovery algorithms. Implicit token ensures that devices transitioning on-line or off-line do not disturb the operation of other nodes. Fast token recovery restores device access following system transients.
---	---

GFK-0248

Introduction

The Genius network, as used in a Series Five PLC system, provides two primary functions: (1) compatibility with Genius I/O blocks, and (2) CPU to CPU communications. The Genius Network consists of up to 32 Genius I/O devices, connected together through a shielded, twisted pair on a serial link which may be up to 7500 feet (2283 meters) in length. This network has been designed for the factory environment. It is robust, and is designed to provide both electrical isolation and a high degree of noise immunity. Error detection and recovery is fast and automatic.




Figure 2-1. Typical Genius Network for I/O Control

Genius I/O Serial Bus

The Genius I/O serial bus operates similarly to a Local Area Network (LAN), with a token that passes from station to station in an order dictated by the Serial Bus Address (SBA) that is assigned to each device. When the token passes to a device, that device can transmit data. When the transmission is completed, the device signs off, thereby passing the token to the next device in the order. All devices on the bus may receive data at any time. When the token completes a pass of all 32 addresses, a Genius I/O bus scan has been completed and all devices have had the opportunity to transmit as much data as required. Unused addresses are automatically skipped and do not interfere with normal bus operation.




Figure 2-2. Genius I/O Serial Bus Token Passing

The Bus Scan

This repetitive cycle of operation is referred to as the bus scan. During the bus scan the Bus Controller:

- Receives all inputs from I/O blocks on the bus.
- Receives any faults and stores up to 15 faults in a special area of the data registers.
- Updates all outputs on the I/O blocks.
- Sends any command received from the CPU (for example, Clear Circuit Fault) to the appropriate device.
- Times the total bus scan and adjusts it, as necessary, to ensure a minimum bus scan time of 3 ms.




Figure 2-3. Genius I/O Serial Bus Scan

The bus scan is independent of the CPU sweep. During the I/O service portions of the CPU sweep, the Bus Controller:

- Transfers all discrete and analog input data to the appropriate locations in the CPU's I1+ or I2+ table, or registers.
- Receives current outputs from the CPU's O1+ or O2+ table, or registers.
- Accepts any new commands and reports its status and that of the serial bus. It also reports the status of the I/O blocks and provides any new diagnostics to the CPU. By default, diagnostics data is stored in the data registers, starting at location R3850 (this default parameter can be changed).

Typical Genius I/O Bus

A typical bus used for controlling I/O must have at least one Bus Controller, can have up to 30 I/O devices (blocks) and usually has space for one Genius I/O Hand-Held Monitor (HHM), which does not always have to be connected.

GFK-0248

A Genius I/O bus used for CPU-to-CPU communications may have up to 32 Bus Controller-like devices, although 8 or fewer is more typical. One space is usually reserved for use by the Genius I/O Hand-Held Monitor.

Interfacing With Genius Networks

Genius I/O blocks are available in a variety of models, and offer compatibility with many field devices, both input and output. To be used in a Series Five PLC control system, the Genius I/O bus must be connected to a Bus Controller (Genius Bus Controller) in a Series Five PLC. The Bus Controller must be located in a Series Five CPU base unit, and a CPU base unit can accommodate up to 8 Bus Controllers.

The Serial Bus Address

As mentioned earlier, each device on the bus must be assigned a unique Serial Bus Address (also called Device Number or Block Number). To assign a Device Number to a Genius I/O block, the HHM must be connected directly to the block, then the address can be programmed through the HHM's Program Block ID screen. Once programmed, the address is stored in the block's non-volatile memory and never has to be reprogrammed. The Serial Bus Address of the Genius Bus Controller is determined by the setting of the DIP switches on the smaller (daughter) board, which is a part of the Genius Bus Controller module.

Starting Reference Address

In order for the Series Five PLC to operate with I/O blocks via its Input (I+) and Output (O+) tables, and registers, each block must be assigned a starting reference address using the Genius Hand-Held Monitor. The number of references used will vary from block to block. The reference addresses assigned to a block cause that block to occupy the same space in both the I+ and O+ tables independent of block type or block configuration. If there is no output data or less output data than input data, then the input data transmitted by the block determines the total number of references used, and the reverse is true if the output data is larger than the input data.

Reference addresses assigned must not overlap or conflict with any references assigned to other devices connected to the Series Five PLC. The HHM, version 3.0 (or later), will perform all of these checks automatically for a Bus Controller connected to a Series Five PLC, when the *HOST CPU Selected* is Series Five. It is not possible to automatically check for conflicts with other I/O devices, or even blocks on separate Genius I/O buses. The user must assume this responsibility.

Other configuration elements may be configured for each block, using the HHM, as required for your particular application. However, as far as system operation is concerned, only the Serial Bus Address and the Reference Address *are required*. For further information on configuration of Genius I/O blocks, refer to GEK-90486, the *Genius™ I/O System User's Manual*.

Supporting Genius Communications Between CPUs

In addition to the handling of I/O data, there are two other forms of Genius communications. They are referred to as Datagrams and Global Genius communications.




Figure 2-4. Genius Network for CPU to CPU Communications

Datagrams

Datagrams are designed to handle infrequent messages, such as fault reports. Since it is important to know whether this type of message gets through to the intended receiver, each message is ACKnowledged on receipt. If an ACK is not received, it causes the transmitting device to retry or inform the host of an error condition.

As supported in the Series Five PLC, datagrams allow reading or writing of any CPU table memory from another CPU. Refer to the RD CCM and WR CCM instructions for further information. This information can be found later in this manual, and in GFK-0023, *Logicmaster™ 5 Programming and Documentation Software User's Manual*.

Report Fault datagrams are handled automatically by Genius I/O diagnostic software in the Series Five CPU and Logicmaster 5 (version 2.01 or later). Datagrams can also be used in conjunction with the TRANSFER instruction.

GFK-0248

Global Data Communications

Global Data communications are designed to handle repetitive data exchanges between CPUs attached to a single Genius I/O bus. A Genius Bus Controller configured to perform Global Data communications will transmit the contents of a group of registers, extracted from the PLC in which the Genius Bus Controller is located, each time it gets its turn on the Genius I/O bus. This transmission is broadcast to all other devices on the bus. Each Global Data device on the bus will transfer the contents of the message to a corresponding location in the memory of its host PLC or CPU. Because of this scheme, the group of registers from the originating Series Five PLC may be copied to all other PLCs and/or CPUs on a regular basis for their internal use.

Combining Global Data Communications and I/O Control

There are basically no restrictions preventing the mixing of Genius I/O control and Global Data communications on a single Genius I/O bus. However, the system performance must be carefully examined before the two are mixed. The user should be aware that inputs from blocks are effectively sent as Global Data. As such, any inputs on a bus will be seen by all Genius Bus Controllers on that bus. This happens regardless of which Genius Bus Controller is sending outputs.

The update rate of an I/O system is generally a sensitive performance parameter. Contributions to the bus scan time vary from block to block and are detailed in the Genius I/O System User's Manual. Typical Genius I/O busses require 10 to 20 ms per bus scan at the fastest data rates (153.6 Kbaud). Each Global Data device on the bus will add 1.3 ms for the default (eight register) scheme described above. A 64 register Global Data transmission will take 9.4 ms at 153.6 Kbaud.

NOTE

Since the Genius I/O update rates are significantly affected by the addition of Global Data devices, it is very important to carefully examine the impact of mixing the two.

Redundancy

Bus Controllers support two forms of redundancy: dual bus redundancy and dual controller redundancy.

Dual Bus Redundancy

Dual bus redundancy allows a Genius I/O system to be wired to continue operation even if a cable is cut or disconnected. In this type of system, two Genius Bus Controllers are used, each connected to separate Genius I/O cables. Both cables are wired to a Bus Switching Module (BSM), catalog number IC660BSM120, which allows only one cable to be connected to the I/O blocks downstream from it. With this scheme, the I/O blocks are under control of only one Genius Bus Controller at any given time.

The BSM may be switched by the PLC or the HHM for the purpose of exercising its ability to switch busses. It will also be switched automatically by the I/O block to which it is attached (the BSM Controller), if communications between the controlling Genius Bus Controller and the block is disrupted for three consecutive Genius I/O bus scans.

If a bus switch occurs for any reason, the controlling Genius Bus Controller will experience a loss of block for each I/O block affected by the switch. The second Genius Bus Controller will experience an identical number of block additions. If the two Genius Bus Controllers are connected to the same PLC, which is the normal case, the transition from one bus to the other will be marked only by the burst of loss and addition of block diagnostics. If the two Genius Bus Controllers are in different PLCs, the responsibility for controlling the blocks will also move from one PLC to another.

Dual Controller Redundancy

Dual controller redundancy is intended to allow blocks to continue operation even following the loss of a PLC and/or Genius Bus Controller. To set up such a system, two PLCs, each having one Genius Bus Controller, are wired together on a single Genius I/O bus along with the I/O blocks. The Serial Bus Addresses of the Genius Bus Controllers must be 30 and 31. Each I/O block automatically transfers all diagnostic messages to both Genius Bus Controllers. Each I/O block on the bus must be configured to accept data from the two Genius Bus Controllers. This is done using the HHM CPU Redundancy menu, which provides two options: Hot Standby Mode and Duplex Mode.

Hot Standby Mode

All blocks with output circuit capability (analog and discrete) have the option of running in the Hot Standby mode. In this mode, the output data from the Genius Bus Controller at SBA 31 is used in preference to the data from the Genius Bus Controller at SBA 30, until such time as data ceases to come down from the Genius Bus Controller at SBA 31. Immediately, the blocks start using the output data being transferred by the Genius Bus Controller at SBA 30, and will continue to do so until data is again available from the Genius Bus Controller at SBA 31.

Duplex Redundancy Mode

Discrete blocks have a second option, called the Duplex Redundancy mode. output circuit, the commanded state from the two Genius Bus Controllers is compared. If they are identical, the circuit is set to the commanded state. If the two Genius Bus Controllers command different output states, the tie is decided by the Duplex Default State, which is preprogrammed into the block by the HHM (this menu follows the CPU Redundancy menu).

GFK-0248

Before installing a Genius Bus Controller, it must be configured to suit the requirements of your application. The following information provides detailed installation procedures. If you are installing a Bus Controller in a version C or earlier Series Five CPU, refer to Appendix E.

Bus Controller Location in a System

A Bus Controller can be installed in any of the I/O slots in a Series Five CPU base unit, which allows up to 8 Bus Controllers in a CPU base unit (see note below). *Bus Controllers cannot be installed in I/O expansion base units.* Each Bus Controller can have up to 31 other Genius I/O devices connected to it. These devices can be Genius I/O blocks, other Bus Controllers, or a Hand-Held Monitor. Each device on each bus must be assigned a Serial Bus Address (SBA) from 0 to 31.

NOTE

There is a maximum limit of eight Bus Controllers and/or CCM Communications modules for any given Series Five system. Both Bus Controllers and CCM modules must be located in the CPU base unit.

If located at the end of the Genius I/O serial bus, the Bus Controller must terminate the serial bus cable by connecting an appropriate resistor between the Serial 1 and Serial 2 terminals (75 Ω and 150 Ω are typical values).

Bus Controller Installation and Configuration

Before installing a Bus Controller in a Series Five CPU base unit, the DIP switches on the module must be configured. Location of the DIP switches is shown in the illustration of the Bus Controller. Use the following table as a guide to configuration of the DIP switches.

The DIP switches are set to the default configuration at the factory before shipment. The factory settings are the default settings referenced in the table. The configuration parameters which must be set with the DIP switches are:

- Serial bus address
- Baud rate
- Output enable bits

DIP Switch		Serial Bus Address																																*		
Position		0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1			
1		o	x	o	x	o	x	o	x	o	x	o	x	o	x	o	x	o	x	o	x	o	x	o	x	o	x	o	x	o	x	o	x	o	x	
2		o	o	x	x	o	o	x	x	o	o	x	x	o	o	x	x	o	o	x	x	o	o	x	x	o	o	x	x	o	o	x	x	o	x	
3		o	o	o	o	x	x	x	x	o	o	o	o	x	x	x	x	o	o	o	o	x	x	x	x	o	o	o	o	x	x	x	x	o	x	
4		o	o	o	o	o	o	o	x	x	x	x	x	x	x	x	o	o	o	o	o	o	o	o	o	x	x	x	x	x	x	x	x	x		
5		o	o	o	o	o	o	o	o	o	o	o	o	o	o	o	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x		

	Baud Rate (K)			
	153.6K	38.4	76.8	153.6
	Extended			Standard *
6	x	o	x	o
7	x	x	o	o

	Output Enable Bits	
	Enabled	Disabled *
8	x	o

* = Default settings (factory shipped)

Serial Bus Address = 31

Baud Rate = 153.6 Kbaud (standard)

Outputs Disabled (i.e., all 32 outputs enabled bits are initialized to "disabled".

x = 1 (closed position) o = 0 (open position)

DIP switch 8 should be closed (outputs enabled) if bus controller is used with revision C and later CPU. If used with a revision B CPU, this switch must remain open.

Selection of Serial Bus Address

The Serial Bus Address is set with DIP switch positions 1 through 5. The factory default for the Serial Bus Address is 31, which is the address usually assigned to a Bus Controller. If a different Serial Bus Address is required, configure the DIP switches accordingly.

Selection of Serial Bus Baud Rate

The factory default setting for baud rate is DIP switch positions 6 and 7 both open, which sets the baud rate to 153.6 Kbaud (standard). Depending on the length of the bus and other factors, it may be desirable to change this to 76.8 Kbaud, 38.4 Kbaud, or 153.6 Kbaud extended. For detailed information on when to use 153.6 Kbaud extended, refer to the Genius I/O System User's Manual. All devices on one bus (including Bus Controller and Hand-Held Monitor) must be setup for the same baud rate. However, busses connected to the Series Five PLC through other Bus Controllers may use different baud rates.

GFK-0248

Setting the Outputs Enable DIP Switch

DIP switch position 8 causes all 32 Outputs Enabled bits (see discussion on setting the Output Enable Bits on page 3-6) to be initialized. Later in the power cycle it is overridden by the PLC, according to the parameters previously specified with Logicmaster 5 or the OIU. When using a revision C or later CPU, this switch is always set ON.

Using a Bus Controller with Default Setup Conditions

If the Bus Controller is to be used only with I/O blocks, no additional Bus Controller setup is required, however blocks must be configured using the Genius I/O Hand-Held Monitor (refer to the Genius™ I/O System User's Manual for block configuration information). No special Series Five CPU programming is needed to communicate with the I/O blocks. Once the I/O blocks are assigned a status table address corresponding to a reference address in the I+ or O+ tables, or the register table, the CPU will update the blocks during its normal processing of the I/O tables.

If the Bus Controller is to be used to communicate with other Series Five CPUs using the RD CCM or WR CCM instructions, no additional Bus Controller or Series Five CPU setup is required, however additions to the logic program are necessary. Detailed information on using these instructions can be found later in this manual.

If the Bus Controller is to be used for Global Communications, it is necessary to set the controller reference address and the Global data length as described later.

Installing the Bus Controller

After configuring the DIP switches for the Bus Controller (or Bus Controllers), install the Bus Controller in one of the eight slots in the CPU base unit. Up to eight Bus Controllers can be installed in the CPU base unit. **Bus Controllers cannot be installed in I/O expansion base units.** Ensure that the module is seated properly, then tighten the two captive screw fasteners, one at the top rear and one at the bottom rear of the module. For information on wiring the serial bus, refer to the Genius I/O System User's Manual. The serial bus is connected to the Bus Controller through the four screw terminals on the front of the module. The Genius Hand-Held Monitor can be connected to the Bus Controller by connecting its cable to the 9-pin connector on the Bus Controller.




Figure 3-1. Bus Controller Installation in a CPU Base Unit

Configuration with Logicmaster 5

To configure a system using Logicmaster 5 software, power-up your system and connect Logicmaster 5. Initially, you should have an I/O configuration error because of the new Genius Bus Controller module that has just been installed. If this is the case, you must accept the new I/O configuration which includes the Genius Bus Controller. The new configuration can be accepted while you are in the scratchpad menu (NEW CONFIG). If you don't get an I/O config error, remove the Genius Bus Controller, and perform a NEW CONFIG from the Logicmaster 5 scratchpad menu. Then power-down, reinsert the Genius Bus Controller, get the I/O config error, and do a NEW CONFIG. This procedure is necessary since the Series Five CPU reads all the Genius Bus Controller DIP switches only when a Genius Bus Controller is first inserted in a slot (causing an I/O Config error), followed by the New Config.

NOTE

The Genius Bus Controller parameters are stored in the memory cartridge in the CPU. If a memory cartridge is moved from one system to another it may need to be initialized, and the Genius parameters set-up in the new system.

Operation with Genius I/O Blocks

The Bus Controller must be set up as previously described (see guidelines below), and the Genius I/O blocks must be configured using the Genius I/O Hand-Held Monitor.

NOTE

For detailed information on configuring Genius I/O blocks, refer to GEK-90486, which is the Genius™ I/O System User's manual.

Some general rules and examples for operation with I/O blocks are provided below. These examples explain how the Bus Controller works with various types of blocks and different reference types.

GFK-0248

Genius I/O Block Setup Procedures

Genius I/O blocks can be assigned CPU addresses in the IO1+ or IO2+ tables as well as in the register tables.

- Step 1:** Note that the Serial Bus Address of the Genius Bus Controller is as described earlier in this chapter. Blocks must be assigned different addresses. Also check that DIP switch 8 is in the Enabled position to allow immediate operation with Genius I/O blocks.
- Step 2:** Assign reference addresses for the blocks using the rules below as guidelines.

Table 3-1. Genius I/O Reference Address Assignment

STATUS TABLE ADDRESS DESIRED BY USER (DECIMAL FORMAT)	STATUS TABLE ABSOLUTE ADDRESS (DECIMAL FORMAT)	STATUS TABLE ABSOLUTE ADDRESS (HEXADECIMAL FORMAT)
IO1+0001 to IO1+1024	0001 to 1024	0001H to 03F9H
IO2+0001 to IO2+1024	1025 to 2047	0401H to 07F9H
R00001 to R04096	32769 to 36864	8001H to 9000H
R04097 to R 16384 *	32865 to 49152 *	9001H to C000H *

* Valid only for CPUs having 16K of registers installed.

Rule 1 - Equal space is always used in the I+ and O+ tables, even if blocks are configured as input-only or output-only (see rules below for register tables). It is recommended that blocks with with configurable points be set as "combo" blocks.

Rule 2 - Addresses used are the greater of input data length or output data length.

Rule 3 - Analog blocks are not multiplexed. A 4 input/2 output analog block will occupy 64 points in both I and O tables.

Rules 4 through 7 apply when Genius Blocks are being mapped into CPU registers.

Rule 4 - Registers are assigned to inputs first, then outputs.

Rule 5 - Inputs and outputs will not be in the same register. If there is an odd number of bytes for the length, the last byte is contained in the eight Least Significant Bits (lower byte), and the eight Most Significant Bits (upper byte) are not used (contain zeros).

Rule 6 - Whole registers (16 bits) are used, even for eight point blocks.

Rule 7 - The total address range occupied by the block is the sum of the number of input registers plus the number of output registers used.

For example, IO1+0001 corresponds to Genius I/O Reference address 00001, and IO2+0001 corresponds to 01025. Register R00001 corresponds to 32769. For Genius I/O blocks assigned to I/O tables, address plus range length cannot exceed the maximum address +1. For Registers, the address plus *both* lengths cannot exceed the maximum address +1. This is because you cannot specify a starting address and a length that goes beyond the end of the table space.

It should be noted that I/O points mapped into the IO1+ and IO2+ tables can be overridden, but I/O points mapped into the register table cannot be overridden. Depending on your application, it may be better to map blocks which occupy large amounts of space, such as analog, high speed counter, and power monitor, into the register table rather than the IO+ tables.

Examples of Address Assignments

Example 1: A 4I/2O Analog block assigned to I1+0001 (reference = 0001) occupies 64 references in both I+ and O+, i.e. I1+0001 through 0064 and O1+0001 through 0064 (although bits O1+0033 through O1+0064 contain no useful data). This is because there is more input data than output data, and each of the four input channels uses 16 bits.

Example 2: A 4I/2O Analog block assigned to R00001 occupies R00001 through R00004 for the 4 Input channels, and R00005 and R00006 for each of the output channels.

Step 3: Set the block configuration using the HHM, version 3 or greater (refer to the Genius I/O User's manual for detailed information).

After the blocks have been properly configured, they are accessed in the user's logic program at the references assigned to them with the Hand-Held Monitor. If the blocks have been assigned an address corresponding to a reference in the I+/O+ tables, the block I/O points may be overridden using Logicmaster 5 or the Operator Interface Unit. If blocks have been assigned a reference address corresponding to a location in the register table, the I/O points cannot be overridden by Logicmaster 5 or the OIU.

Individual circuits can be forced on or off (or to values selected by the user, if the circuit is analog) using the HHM. Only when circuits are not forced, will blocks drive outputs to the state present in the O+ tables. Genius I/O blocks always use exactly the same number of points in the I+ and O+ tables, whether or not there are physical inputs and outputs to match. The number of circuits used varies from block to block, but is always the larger of the number of inputs or outputs used by the block.

Step 4: Set the Output Enable bits.

Depending on your Genius I/O system configuration, it may be necessary to reset some of the the output enable bits for each active Serial Bus Address on each bus. These bits should have defaulted to "on" during the first power cycle of the Genius Bus Controller. If multiple Genius Bus Controllers are used on the same bus, the output enable bits must be set so that only one of the bus controllers has its outputs enabled to any single Serial Bus Address.


The output enable setup is done using Logicmaster 5 or the OIU. A field of 32 bits is presented for each Genius Bus Controller. Each bit corresponds to the enable/disable status of one of the Serial Bus Addresses. If the bit is set to 1, that Serial Bus Address is enabled, if a 0 it is disabled. The Genius setup screen is as shown.

GFK-0248

CPU:RUN/ENBL/UNLOCKED		CPU ID: 1		LM NOTEQ CPU	LM:ONLINE	11:59:36
G E N I U S B U S C O N T R O L L E R S E T U P						
	EQUIVALENT STATUS TABLE	GLOBAL DATA LOCAL	GLOBAL DATA TRANSMIT	(FUTURE) RECEIVE DIRECTED	SBA OUTPUT ENABLE BITS	
SLOT NUMBER	ADDRESS	REFERENCE	LENGTH	LENGTH	31-16	15-00
0					F437	FFF1
1	Do not fill in any of these columns if all					
2	you are interested in is using Genius I/O blocks.					
3						
4	These columns <u>are</u> important if you are using					
5	global data.					
6						
7						
PRESS HELP KEY FOR LIST OF VALID RANGES						
NOTE: FOR APPLICATIONS WITH A SINGLE CONTROLLER PER BUS, THE LOCAL REFERENCE, TRANSMIT, AND DIRECTED LENGTH SHOULD BE SET TO 0.						
LOAD	STORE	CLEAR	CALC	SETUP		
1FM CPU	2TO CPU	3 CPU	4 REF	5	6	7 8& DIAG

The format of the output enable bits is as shown below:

Sample data as shown on screen = F437 FFF1



You must decide which Serial Bus Addresses need to be enabled and set the appropriate bit to a 1. Then enter the resulting number as hexadecimal data. Data (0000 - FFFF) is entered at the cursor location, and stored to the CPU using the Logicmaster 5 STORE TO CPU softkey.

If a Genius Bus Controller is being used with Genius I/O blocks, and no other controllers are on the bus, the output enable bits will default to the ENABLE position (FFFFH); no further setup is required in this case. Unused Serial Bus Addresses can have their output enable bit set to a 1 with no difficulties.

If multiple Genius Bus Controllers are being used on the same bus, outputs to any single Serial Bus Address can be enabled only on one controller, and requires the appropriate bit to be reset to 0 at all controllers, except one.

After disabling the desired Serial Bus Addresses by setting the appropriate output enable bits to 0 or 1, the following capabilities have been enabled, and require no further setup.

1. Operation with Genius I/O blocks (the blocks must be configured using the Genius Hand-Held Monitor, but no further Series Five setup is required). As noted previously, a block address of 1 - 1024 will map the block in the IO1+ tables. A block address of 1025 - 2047 will map the block in the IO2+ tables. A block address of 32768 or above will map the block into the register table.
2. General purpose communications between Series Five CPUs by use of the RD CCM and WR CCM user logic commands. These commands can be used with the Genius Bus Controller as well as with the CCM Master Module. This capability provides true peer to peer operation under user logic control. It is normally used to exchange lower priority data which does not need to be updated on each Genius bus scan.
3. General purpose communications to many different GE Fanuc products through the Genius Datagram capability (refer to Appendices C and D for examples).

Enabling and Changing Global Data Values

Global Data is a convenient way to allow CPUs to communicate automatically. It may be used on the same bus that uses Genius I/O, or on a separate bus by itself.

Once it is properly configured, global data is automatically sent by the CPU to all compatible devices on the Genius bus. Global data will automatically be received and stored with no setup required. Global data setup is not required when using the Series Five only to drive Genius blocks.

For example, if your local CPU is set up with a global data reference of 32869 (Register 100), and global data transmit length of 10, then registers 100 through 109 will be transmitted on each Genius bus scan to all devices on the bus capable of receiving global data transmissions. If another Series Five CPU, or a Series Six CPU is active on the Genius bus, they will see R100 through R109 data from your local CPU appear in their register tables at the same locations. Only the transmitting (broadcasting) device needs to be set up since reception is automatic.

NOTE

Care must be taken to ensure that more than one bus controller is not broadcasting from the same status table addresses.

Changing the Global Data Setup

The Genius Bus Controller setup may be altered through either the Bus Controller Setup menu in Logicmaster 5, or sub-menu 91 - Set Genius Bus Controller, in the Series Five Operator Interface Unit (OIU). Changing the Global Data Transmit Length and/or the status table address affects the Global Data transmitted by the Genius Bus Controller. A Global Data Transmit Length of zero stops Global data transmissions. The maximum transmission length is 64 registers. These same menus in Logicmaster 5 or the OIU may be used to set up a Genius Bus Controller at any address (0 - 31) as a Global Data device.

GFK-0248

Configuration Parameters for Global Data Communications

Parameters that must be configured to allow Global data are:

- Reference (status table) address of the Genius Bus Controller
- Broadcast data length for the Genius Bus Controller

Refer to Table 3-2 for a list of the valid Bus Controller ranges for the parameters listed above.

Entering GBC Setup Parameters With the OIU

When using the Operator Interface Unit, the required Genius Bus Controller setup parameters are entered by accessing sub-menu 91 and following the prompts displayed on the LCD screen. Valid ranges for each of the required parameters are listed in Table 3-2. Refer to GFK-0181, the Series Five Operator Interface Unit User's Manual, for further details.

Editing GBC Setup Parameters With Logicmaster 5 Software

If communication with the CPU is established, the setup values of the Bus Controller are automatically loaded from the CPU. These setup values can be displayed and/or edited and then stored back to the CPU. This section explains how to display and edit these setup values.

Displaying the Bus Controller Setup Screen

When the GENIUS BUS CONTROLLER SETUP (F5) key is pressed from the Setup/Diagnostic Functions menu, the Genius Bus Controller Setup screen will appear. Genius Bus Controller setup data will be loaded from the CPU if communication has been established.

CPU:RUN/ENBL/UNLOCKED		CPU ID: 1	LM NOTEQ CPU	LM:ONLINE	11:59:36
G E N I U S B U S C O N T R O L L E R S E T U P					
SLOT NUMBER	EQUIVALENT STATUS TABLE ADDRESS	GLOBAL DATA LOCAL REFERENCE	GLOBAL DATA TRANSMIT LENGTH	(FUTURE) RECEIVE DIRECTED LENGTH	SEA OUTPUT ENABLE BITS 31-16 15-00
0	R0100	32869	10	0	F437 FFF1
1				Not	Not
2		Fill	and	Used	Used
3		in	this	for	for
4		this	column	global	global
5		column		data.	data.
6				Leave	Set-up
7				at 0.	for blocks.
PRESS HELP KEY FOR LIST OF VALID RANGES					
NOTE: FOR APPLICATIONS WITH A SINGLE CONTROLLER PER BUS, THE LOCAL REFERENCE, TRANSMIT, AND DIRECTED LENGTH SHOULD BE SET TO 0.					
LOAD	STORE	CLEAR	CALC	SETUP	
1FM CPU	2TO CPU	3 CPU	4 REF	5	6 7 8& DIAG

Bus Controller Setup Key Summary

The Genius Bus Controller Setup screen displays the following function keys:

LOAD FM CPU (F1): Select LOAD FROM CPU to load Bus Controller setup values from the CPU.

STORE TO CPU (F2): Select STORE TO CPU to store the Bus Controller setup values to the CPU.

CLEAR CPU (F3): Select CLEAR CPU to clear the Bus Controller setup values in the CPU.

CALC REF (F4): Select CALCULATE REFERENCE to display the CPU table addresses which correspond to the Genius Bus Controller reference addresses.

SETUP & DIAG (F8): Select SETUP & DIAGNOSTICS to return to the Setup and Diagnostic Functions menu.

STORE and CLEAR functions require that the CPU be stopped and the Logicmaster system be on-line. You must also confirm the initiation of a LOAD, STORE, or CLEAR operation.

The Up, Down, Right, and Left cursor keys are used to select a field to be edited. Move the cursor to a particular field, and enter the values. All values are expressed as decimal numbers, except the Output Enable field, which is hexadecimal values. Leading zeros are not necessary.

The Clear key is used to blank the selected field, while the Delete key removes only the last digit entered. Since the addresses used are Genius I/O Reference addresses, you can press the CALC REF (F4) key to update the left column, which shows the corresponding CPU table addresses.

Setup Ranges

It is necessary to select the starting table address of the local CPU/Bus Controller in the global memory map. Using the following table, which lists the valid setup ranges of the Bus Controller, select the desired starting location of the data to be transmitted to the other units. This number is entered in the GENIUS DATA LOCAL REFERENCE field. The number of bits or words to be transmitted is then entered in the GLOBAL DATA TRANSMIT LENGTH field. The RECEIVE DIRECTED LENGTH should remain at 0, and the applicable OUTPUT ENABLE BITS should be set as described earlier if this bus controller will also be controlling Genius outputs.

The reference address range determines which of two address types is used. Bit addressing is used for I/O table data, and word addressing is used for register data. The length is entered in bits for bit addresses (I/O table data) and words for word addresses (register data). Bit-related values (I/O addresses and lengths) will be rounded to byte boundaries when stored to the CPU.

Table 3-2. Valid Bus Controller Setup Ranges

TYPE OF ADDRESS	GLOBAL DATA LOCAL REFERENCE	EQUIVALENT STATUS TABLE ADDRESS	GLOBAL DATA TRANSMIT LENGTH
Bit	00001 - 01024	IO1+0001 - IO1+1024	0000 - 1024 bits
Bit	01025 - 02048	IO2+0001 - IO2+1024	0000 - 1024 bits
Word	32769 - 36864	R00001 - R04096 (4K REG)	0000 - 0064 words
Word	32769 - 49152	R00001 - R16384 (16K REG)	0000 - 0064 words

GFK-0248

Where: IO1+xxxx addresses = the I/O number.
 IO2+xxxx addresses = the I/O number + 1024.
 Reference address for registers = register number plus 32768.

Reference Address

When using the Operator Interface Unit, the Series Five PLC table addresses are entered in the following format: I1+XXXX, O1+XXXX, I2+XXXX, or O2+XXXX. This is the same format used to display references of combination Genius I/O blocks in the Genius I/O Diagnostics screen of Logicmaster 5. When using Logicmaster 5, the status table reference address must be entered directly.

By using the CONV REF softkey, the status table reference address is translated to a table reference on the Logicmaster 5 screen.

The correspondence between the table values and the nearest byte boundary to get the logical address.

Global Data and Transmit Data Lengths

Global and transmit data lengths are expressed as the number of bits of data to be transferred. Bit reference tables (I+/O+ tables) are entered as the number of bits of broadcast or directed data to be transferred. The OIU or Logicmaster 5 converts these user entered values to bytes (value is divided by eight and rounded up). Word reference addresses are entered as the number of registers to be transferred. The OIU or Logicmaster 5 converts the number of registers specified to bytes (two times the value entered).

Table 3-3. Global Data And Transmit Data Lengths

DATA LENGTH ENTERED BY USER	CONVERTED VALUE WRITTEN TO SCRATCH PAD
0 to 1024 Bits	0 to 80H Bytes
0 to 64 Registers	0 to 80H Bytes

Data lengths are expressed as the number of registers or I/O points to be transferred. Range checking of the field contents is performed when a STORE to CPU (F2) function is selected. If an error is found, it must be corrected and the STORE TO CPU function initiated again.

NOTE

Addresses and lengths of I/O points (IO1+ and IO2+ tables) are adjusted to byte boundaries when stored to the CPU.

The procedures described above should be done for each unit in the global communications network. It is necessary to ensure that the start address + length for each unit does not overlap a table boundary, and does not overlap the configuration of any other units in the network.

Setup of global data is now complete. The CPU at which these settings were made will now broadcast I/O data or registers starting at the global data local reference for the length specified in the global data transmit length.

General System Information

1. The CPU INITIALIZE function will reset all Genius setup parameters to 0, and set output enable bits to disable.
2. The DIP switches on the Genius Bus Controller module are only read when a newly registered Genius Bus Controller has been detected. From that point on, the CPU uses the output enable and baud rate settings that Logicmaster 5 or the OIU have established. If a Genius Bus Controller module is removed from a slot, and "unregistered" with a NEW CONFIG command, then it is reinstalled and re-registered with another NEW CONFIG command, the DIP switch will be read again at this point. Note that the Genius Bus Controller settings are stored in the CPU memory cartridge. This cartridge may need to be re-initialized if it is moved to another CPU with a different Genius configuration.
3. Note that Genius I/O blocks occupy space in both I+ and O+ tables, even if the block is programmed as input only, or output only. Also, analog blocks' data is not multiplexed as it is on Series Six Genius applications.
4. After Genius I/O blocks have had their I/O reference addresses changed, it is necessary to power cycle the blocks to have the new address recognized.
5. The Genius Hand-Held Monitor does not need to have its output enable bit set to work on the bus, and it will have a reference address of 32767.
6. There is not an internal address conflict check between addresses to which Genius blocks have been assigned, and addresses that global data is using. Be sure that incoming global data does not overwrite data coming from blocks.
7. When a datagram is sent to the Series Five CPU, the address map is different than with Series Six. For example, the target address for a Series Six could be 0000H 0040H. The address consists of the format WX YZ where Y is always 0, and ZW is the address, and X is not used. For the Series Five, Y MUST BE 85H. The Series Five internal address would be ZW. To read register 1 from a Series Five CPU, you need to use address 0000H 8500H. Register 2 would be 0200H 8500H. The formula for the register address is (Register number - 1) x 2. For register 1000, the address would be 1998 decimal (07CEH), and the address field would be CE00H 8507H.

The Series Five internal mapping FOR DATAGRAMS is as follows:

Table 3-4. Datagram Mapping

Range and Reference Numbers	Series Five Internal Address (ZW above)
R1 - R16384	0000H to 7FFFH
I1+1 to I1+1024	8000H to 807FH
I2+1 to I2+1024	8080H to 80FFH
O1+1 to O2+1024	8100H to 81FFH
I1 to I1024	8200H to 827FH
O1 to O1024	827FH to 82FFH
O1-1 to O2-1024	8300H to 83FFH
I1-1 to I1-512	8500H to 85FFH

Refer to Appendix C for a detailed example of using datagrams.

GFK-0248

8. When using a TRANSFER command in a Series Five logic program to access Series Five internal memories, the above offset address applies. However, the source and target addresses would be of the format

8005H OFFSET, e.g. for I1, 8005H 8200H.

The TRANSFER command can be used to send datagrams to other Genius devices. Refer to Appendix D for more details on this use of the TRANSFER command. Also, refer to the TRANSFER instruction definition in the Logicmaster 5 Programming and Software Documentation User's Manual, GFK-0023, for more details.

Series Five CPU Scratchpad Genius Definitions

The Series Five CPU scratchpad contains Genius related information. This information is updated only after a bus controller has just been accepted into the I/O configuration.

The following table is a list of this Genius information in the scratchpad. It is not necessary to use any of this data for normal Genius operation.

Table 3-5. Genius Information in CPU Scratchpad

Scratchpad Relative Address (Byte)	Definition
256H	0 (slot number)
257H	Serial bus address of Genius Bus Controller in slot 0 (0-31)
258H	Status table address - 1st byte
259H	Status table address - 2nd byte
25AH	Number of Inputs to broadcast (Global data)
25BH	Number of Outputs to receive (future)
25CH	Data rate
25DH	Unused
25EH	Output enable bits - SBA 0-7
25FH	Output enable bits - SBA 8-15
260H	Output enable bits - SBA 16-23
261H	Output enable bits - SBA 24-31
262H to 26DH	1 (slot number) - above information repeated for slot 1
26EH to 279H	2 (slot number) - above information repeated for slot 2
27AH to 285H	3 (slot number) - above information repeated for slot 3
286H to 291H	4 (slot number) - above information repeated for slot 4
292H to 29DH	5 (slot number) - above information repeated for slot 5
29EH to 2A9H	6 (slot number) - above information repeated for slot 6
2AAH to 2B5H	7 (slot number) - above information repeated for slot 7

GFK-0248

Introduction

This chapter describes the use of the Read CCM and Write CCM instructions in a Genius network to communicate with other Series Five PLC systems with Genius Bus Controllers.

Use of Read CCM and Write CCM to Communicate with Other CPUs

The Read (RD) CCM and Write (WR) CCM instructions provide a user friendly method to obtain information from another CPU, or send data to another CPU. These instructions can be used with either the CCM Communications module to any CCM slave device, or, as presented here, with the Genius Bus Controller to another Series Five CPU with a Genius Bus Controller. When used with the Bus Controller, the underlying mechanism for the data transfer is through datagrams. These instructions can be used to obtain CPU table information as listed in the following table.

Table 4-1. CCM/CPU Mapping

Table Name	Range and Reference Numbers	Offset Values	Target Memory Type for Table	Target Memory Type for Override	Data Format
Registers	R00001-R16384 (for 16k reg)	0001H-4000H	1	N/A	2 Bytes/Register
	R00001-R04096 (for 4k reg)	0001H-1000H	1	N/A	2 Bytes/Register
I1+ Inputs	I1+0001 to I1+1024	0001H-0080H	2	4	8 Inputs/Byte
I2+ Inputs	I2+0001 to I2+1024	0081H-0100H	2	4	8 Inputs/Byte
Local Inputs	I0001 to I1024	0101H-0180H	2	4	8 Inputs/Byte
Special Inputs	I1-0001 to I1-0512	0181H-01C0H	2	N/A	8 Inputs/Byte
O1+ Outputs	O1+0001 to O1+1024	0001H-0080H	3	5	8 Outputs/Byte
O2+ Outputs	O2+0001 to O2+1024	0081H-0100H	3	5	8 Outputs/Byte
Local Outputs	O0001 to O1024	0101H-0180H	3	5	8 Outputs/Byte
Internal Coils	O1-0001 to O1-1024	0181H-0200H	3	5	8 Inputs/Byte
Internal Coils	O2-0001 to O2-1024	0201H-0280H	3	5	8 Outputs/Byte
Scratch Pad *	0000 to 0900H	0000-0900H	6	N/A	1 Byte/Byte
User Logic	0000 to 16,383	0000-3FFFH	7	N/A	2 Bytes/Word

H = Hexadecimal

* Extreme care must be used when writing to any Scratch Pad location area. This is not recommended without specific information from GE Fanuc.

NOTE

The Genius version of RD/WR CCM cannot be used in conjunction with Series Six programmable controllers (although this can be done when using CCM modules). Refer to Appendix D for an example of datagram communications between a Series Five PLC and a Series Six PLC.

Read/Write CCM

The following discussion provides more information on the Read CCM and Write CCM instructions. Examples of their use are also provided. The Read CCM and Write CCM instructions move data to and from the Series Five Genius Bus Controller. You can use the READ CCM instruction to request data from a remote Series Five PLC through the Bus Controller to a data register buffer in the local CPU. With the Write CCM instruction, you can send data from the local CPU through the Bus Controller to a remote Series Five CPU with a Bus Controller. Each of these instructions has a single register operand which specifies the starting address of a block of six registers containing the following information:

- Slot number of the local Bus Controller.
- Target Address (Serial Bus Address)
- Target memory type.
- Starting address within the memory type of the remote target device.
- Length of the data to be transferred.
- Starting register in the local CPU for the data buffer.

Symbology:

R***** R*****
-|RDCCM|- or -|WRCCM|-

Operation:

Before execution, the following registers must contain the data listed below. (Refer to the previous table for information on CCM/CPU mapping.)

Read CCM:

R***** = Slot number of Genius Bus Controller.
 + 1 = Serial Bus Address (SBA) of the remote Genius Bus Controller.
 + 2 = CCM memory type to read from (see CCM/CPU Mapping, Table 5-1).
 + 3 = Start address in target.
 + 4 = Length to read (registers). Maximum length is 64.
 + 5 = First register in local receive buffer.

Write CCM:

R***** = Slot number of Genius Bus Controller.
 + 1 = Serial Bus Address (SBA) of the remote Genius Bus Controller.
 + 2 = CCM memory type to write to (see CCM/CPU Mapping, Table 5-1).
 + 3 = Start address in target.
 + 4 = Length to write (registers). Maximum length is 64.
 + 5 = First register in local transmit buffer.

After execution, the receive data buffer register pointed to by R***** +5 will contain the data from the remote CPU.

Special internal bits affected are I1-0081 to I1-0204, and I1-0045 for the Bus Controller. Refer to page 5-7 for a description of these bits.

GFK-0248

Example of Reading from a Remote CPU:

To read inputs I0017 through I0048 from the remote Series Five PLC with a Bus Controller module with SBA 28:

1. Preset the registers with the following data:

```
R01001 = 05    (slot number of local Bus Controller module)
R01002 = 28    (SBA of remote Bus Controller)
R01003 = 02    (memory type = input table)
R01004 = 103H  (start address for input table, I0017)
R01005 = 02    (number of words to fetch; also, length of data buffer)
R01006 = 0200  (data buffer to start at register R0200)
```

2. Execute the following:

```
R01001
-|RDCCM|-
```

3. During execution, status bit I1-0091 will indicate the transfer status for slot 5:

0 = done 1 = executing

Status bit I1-0092 will indicate the error status for slot 5:

0 = OK 1 = error

The data buffer for this example will contain the following data:

```
R00200 = 0002 (inputs 17, 19-32 are 0, input 0018 is 1)
R00201 = 0004 (inputs 33, 34, 36-48 are 0, input 35 = 1)
```

Example of Writing to a Remote Series Five PLC with a Genius Bus Controller:

To write data buffer (R00220 - 00222) to outputs 1 - 48 through a remote Series Five PLC with a Bus Controller module with SBA 25 (the local Bus Controller module is in slot 2):

1. Load R00220 - 00222 with the data to be sent.
2. Preset the registers as follows:

```
R00501 = 02    (local Bus Controller module is in slot 2)
R00502 = 25    (target SBA)
R00503 = 03    (target memory type = output table)
R00504 = 0101H (starting address for outputs 1-48)
R00505 = 03    (number of words to send)
R00506 = 220   (start data buffer at register 220)
```

3. Execute the following:

```
R00501
-|WRCCM|-
```

4. During execution, status bit I1-0085 will indicate the transfer status for slot 2:

0 = done 1 = executing

Status bit I1-0086 will indicate the error status for slot 2:

0 = OK 1 = error

GFK-0248

Introduction

The purpose of the Genius I/O Diagnostics function in a Series Five PLC control system is to find faults in the Genius I/O system. The types of faults detected by the Genius I/O Diagnostics include:

- Failure of a Bus Controller module in the CPU base unit.
- Excessive bus communication errors.
- Address conflicts
- Circuit faults reported by devices on the bus through Report Fault datagrams.
- Add or loss of device. This is optional through user programming.

In addition to reporting faults, the Genius I/O diagnostic routines allow the user to send *Clear All Faults* and *Pulse Test* datagrams to all appropriate devices on the bus.

User Interface to Genius I/O Diagnostics

The user interface to the Genius I/O diagnostic function is through the Logicmaster 5 diagnostic screen, registers, and internal coils. The user program, OIU, or Logicmaster 5 can manipulate the internal coils to enable/disable the Genius I/O diagnostics, send *Clear All Faults* and *Pulse Test* messages to Genius I/O devices, and indicate to the CPU diagnostic firmware if the addition or loss of a block should be reported as a fault. The diagnostic routine formats the fault information, time stamps it, and places it in the register table in the appropriate location. When diagnostics are enabled, the routine is executed each sweep when the CPU is in the RUN or RUN DISABLED modes. The diagnostic routine is not executed in STOP mode.

Logicmaster 5 interprets the fault data in the registers and displays a formatted table with the fault location, text messages describing the fault, and a time indicating when the fault was logged. The registers are also available to other devices, such as the Series Five ASCII/BASIC Module, which can be programmed to print reports or display the information on an Operator Interface Terminal.

Displaying the Genius I/O Diagnostics Screen

The Genius I/O diagnostics collects and formats fault information and stores it in the fault table in register memory if O2-1024 has been set to a 1. Ten registers are used to report each fault. The maximum number of faults that can be handled by the diagnostic routine is 255.


Fault Table Display

The Logicmaster 5 software reads the fault table and displays pertinent information, including location and type of fault detected, fault description, and a time stamp of when the fault was detected. An example of the Logicmaster 5 screen for the fault table is shown below.

						LM:OFFLINE	15:58:45
G E N I U S I / O F A U L T T A B L E							
TOTAL FAULTS: 06							
TOP FAULT DISPLAYED: 01							
SLOT NO.	REFERENCE ADDRESS	CIRC. NO.	FAULT CATEGORY	FAULT TYPE	FAULT DESCRIPTION	MON DAY	HR:MN:SC
0	I01+0009		DEVICE ADDITION			JUN 27	08:36:51
0	I01+0001		DEVICE ADDITION			JUN 27	08:36:52
0	I01+0145		ADDRESS CONFLICT			JUN 27	08:36:52
0	I01+1045	08	CIRCUIT FAULT	DISCRETE	OPEN WIRE	JUN 27	08:36:52
0			DEVICE LOSS			JUN 27	08:44:35
			DEVICE ADDITION			JUN 27	10:35:23
NEXT PREV CLEAR 1 PAGE 2 PAGE 3FAULTS 4 TOP 5BOTTOM 6 7 8& DIAG							

Contents of Fault Table

When the Genius I/O diagnostics detects a fault, an entry is generated in the fault table in CPU registers. The ten registers which make up a fault table entry are organized as shown below:



The contents of registers 2, 3, 4, 5, 6, and 7 of the fault table entry vary depending on the fault category. The data in registers 1, 8, 9, and 10 of the fault table entry is fixed. The details of the fault entries, which can be found in Appendix A, are not critical to most Genius I/O users.

Special Registers, Contacts, and Coils for Genius I/O Operation

The Series Five CPU provides diagnostic and status information to the user through special registers, contacts, and coils. Many of these diagnostic aids are relevant to Genius I/O operation. In addition, setup of some Genius I/O parameters and commands is done through these special bits and registers.

GFK-0248

Special Registers

The special registers used for Genius I/O diagnostics and other Genius I/O functions are described below.

R3850 through R3999 - These registers are the default registers which are used to store Genius I/O diagnostic fault information.

R4041 through R4048 - These registers contain the Genius I/O bus scan times for the Bus Controllers contained in slots 0 - 7 in the CPU base unit.

On power-up, the CPU writes default values into three registers: R4049, R4050, and R4051. The function of these registers is described in the following table.

Table 5-1. Registers for Genius I/O Diagnostics

REGISTER	WRITTEN BY		DEFINITION
	CPU	USER	
R04049	X	X	START OF FAULT TABLE - This register contains the starting register address of the fault table. It is initialized by the CPU at power-up to 3850D (Decimal). The user program can change the starting address of the fault table from the default value. The CPU only reads this register when the ENABLE GENIUS DIAGNOSTICS bit (O2-1024) transitions from CLEARED to SET, or during power-up if the CPU is in RUN or RUN DISABLED mode and the ENABLE GENIUS DIAGNOSTICS bit is SET.
R04050	X	X	LENGTH OF FAULT TABLE - This register contains the maximum number of faults which the CPU will place in the fault table. It is initialized by the CPU at power-up to 15D. The user program can change the fault table length from the default value. The CPU only reads this register when the ENABLE GENIUS DIAGNOSTICS bit (O2-1024) transitions from CLEARED to SET, or during power-up if the CPU is in RUN or RUN DISABLED mode and the ENABLE GENIUS DIAGNOSTICS bit is SET. The maximum number of faults which can be stored is 255. If the value of this register is greater than 255, the CPU will use 255 as the LENGTH OF FAULT TABLE value.
R04051	X	X	NUMBER OF FAULTS - This register contains the number of faults which are in the fault table. It is initialized by the CPU at power-up to zero. The CPU uses this value as a pointer to the register where the next fault will be stored. The user program can change the value of this register. The CPU reads the register each sweep when diagnostics are enabled, and the CPU is in RUN or RUN DISABLED mode.

R4057 through R4064 - These registers contain the status table address of a bus conflict, if one exists.

R4057 - refers to the Bus Controller in slot 0
 R4058 - refers to the Bus Controller in slot 1
 R4059 - refers to the Bus Controller in slot 2
 R4060 - refers to the Bus Controller in slot 3
 R4061 - refers to the Bus Controller in slot 4
 R4062 - refers to the Bus Controller in slot 5
 R4063 - refers to the Bus Controller in slot 6
 R4064 - refers to the Bus Controller in slot 7

NOTE

If a CCM Communications module is installed in any of the above slots, these registers are used for unformatted receiving, instead of the use described above.

Internal Coils

The operation of the internal coils used for Genius I/O diagnostics is described in the following table.

Table 5-2. Internal Coils for Genius I/O Diagnostics

REFERENCE	WRITTEN BY		DEFINITION
	CPU	USER	
O2-1019	X		SETUP ERROR - If set, the data in registers R04049 - R04051 is incorrect. The register data is only checked when the ENABLE GENIUS DIAGNOSTICS bit (O2-1024) transitions from CLEARED to SET, or during power-up if the CPU is in RUN or RUN DISABLED mode and the ENABLE GENIUS DIAGNOSTICS bit is SET. If a SETUP ERROR exists, the Genius I/O diagnostic routine is not executed.
O2-1020	X		FAULT TABLE OVERFLOW - If SET this bit indicates a fault table overflow exists. An overflow occurs if the value of the NUMBER OF FAULTS register (R04051) is greater than the value of the LENGTH OF FAULT TABLE register (R4050). This bit remains set as long as the overflow condition exists. The CPU will CLEAR the bit when there is no overflow condition. If diagnostics are enabled this bit will be updated every sweep when the CPU is in the RUN or RUN DISABLED mode.
O2-1021	X	X	PULSE TEST - If set, the CPU will send a PULSE TEST datagram to all logged in devices in the system. The CPU monitors this bit, and if it is SET the CPU will direct a PULSE TEST datagram to each logged-in device in the system (a maximum of one PULSE TEST datagram is sent by each bus controller in the system per CPU sweep). When the PULSE TEST datagram has been sent to all devices in the system, the CPU will CLEAR this bit.

GFK-0248

Table 5-2. Internal Coils for Genius I/O Diagnostics - Continued

REFERENCE	WRITTEN BY		DEFINITION
	CPU	USER	
O2-1022	X	X	If diagnostics are enabled, this bit will be checked every sweep when the CPU is in the RUN or RUN DISABLED mode, except when the pulse test or clear all faults function is in progress. If the PULSE TEST bit and the CLEAR ALL FAULTS bit are SET at the same time, the clear all faults function will be performed first. CLEAR ALL FAULTS - This bit, when set initiates a Clear All Faults command to all logged in devices in the system. The CPU monitors this bit, and if it is SET the CPU will CLEAR the NUMBER OF FAULTS register (R04051). The CPU will then direct a CLEAR ALL FAULTS datagram to each logged-in device in the system (a maximum of one CLEAR ALL FAULTS datagram is sent by each Bus Controller in the system per CPU sweep). When the CLEAR ALL FAULTS datagram has been sent to all devices in the system, the CPU will CLEAR this bit. If diagnostics are enabled, this bit will be checked every sweep when the CPU is in the RUN or RUN DISABLED mode, except when the pulse test or clear all faults function is in progress. If the PULSE TEST bit and the CLEAR ALL FAULTS bit are SET at the same time, the clear all faults function will be performed.
O2-1023		X	REPORT ADD/LOSS OF BLOCK AS FAULT - If this bit is SET the addition or loss of a device in the system will be reported as a fault in the fault table, otherwise these conditions are not entered into the fault table. If diagnostics are enabled, this bit will be checked every sweep when the CPU is in the RUN or RUN DISABLED mode.
O2-1024		X	ENABLE GENIUS DIAGNOSTICS - If this bit is SET then Genius I/O diagnostics will be processed by the CPU. If the bit is CLEARED, then the Genius I/O diagnostics routine is not executed, and the CPU will not write to internal outputs O2-1019 through O2-1022. This bit will be checked every sweep when the CPU is in the RUN or RUN Disabled mode.

Clear All Faults and Pulse Test Function

CLEAR ALL FAULTS and PULSE TEST are datagrams. If a Genius I/O device has fault reporting enabled it sends a REPORT FAULT datagram when a fault is first detected. The datagram for a particular fault condition is only sent once (even if the fault lasts for multiple Genius I/O bus scans). When a device receives a CLEAR ALL FAULTS message it clears all its internal fault condition flags. As new or previously existing faults are detected, they set the internal fault condition flags which will cause the appropriate REPORT FAULT datagrams to be transmitted. Fault conditions which have been corrected will prevent the corresponding REPORT FAULT datagram from being repeated; CLEAR FAULT must be sent to the block to allow the block to report a reoccurrence of a previously reported fault.

The CLEAR ALL FAULTS function can be used to determine if a fault condition has been corrected. If the fault condition still exists, the device will report it again after the CLEAR ALL FAULTS datagram has been processed. Logicmaster 5 will display the fault as described previously.

The PULSE TEST function is applicable only to selected discrete blocks. When a discrete device receives a PULSE TEST datagram it initiates the test if it has been configured with pulse test enabled.

If diagnostics are enabled and the CPU is not in the process of executing a pulse test or clear all fault request, it will check the PULSE TEST bit (O2-1021) and the CLEAR ALL FAULTS bit (O2-1022) each time the Genius I/O diagnostic routine is executed. If both bits are zero no action is taken. If one of the bits is set the CPU will initiate the indicated function. If the PULSE TEST bit and the CLEAR ALL FAULTS bit are SET at the same time, the clear all faults function will be performed first. When the CPU is performing the pulse test or clear all faults function it will not check the PULSE TEST and CLEAR ALL FAULTS bits. When the clear all faults or pulse test function is complete the CPU will clear the appropriate bit (O2-1021 or O2-1022).

Device Loss

During the Bus Controller service, which occurs each sweep, the CPU performs a check for loss/addition of devices from the bus. If bit O2-1023 is set, the CPU will build a fault table entry for each device that was lost from the bus. If O2-1023 is not set, the CPU will not build a fault table entry for loss of device.

A loss of device means that the Bus Controller has logged out a device because no Broadcast Control Message has been received from it for three successive Genius I/O bus scans.

Device Addition

During the Bus Controller service, which occurs each sweep, the CPU performs a check for loss/addition of devices from the bus. If bit O2-1023 is set, the CPU will build a fault table entry for each device that was logged in by the Bus Controller, *AND* did not have an address conflict. If O2-1023 is not set then the CPU will not build a fault table entry for addition of device.

An addition of a device means that the Bus Controller has logged in a new device, and the CPU reference address conflict check did not find a conflict.

Address Conflict

If a device has logged in with a reference address that conflicts with a device already on the same Genius I/O bus, an Address Conflict fault will be reported. The CPU is not exchanging control data with this device (its input data is not being transferred to the I+ tables or registers, and the output disabled bit is set to inhibit transmission of O+ or register data to the device). For each conflicting device a fault table entry is made by the CPU.

GFK-0248

Internal Contacts

In addition to the registers and coils described above, two groups of internal contacts have special meaning when used with the Genius I/O system.

I1-0081 through I1-0096 - Indicate completion status of Read/Write CCM transmission for slots 0 through 7 of the CPU base unit. Definitions for each contact reference are as shown below. Each slot has two references associated with it, and each reference has two possible conditions. The first reference indicates if the module in that slot is not executing (0) or executing (1), and the second indicates completion with no error (0) or with error (1).

Slot Number	Reference	Status
Slot 0	I1-0081	not executing/executing
	I1-0082	no error/error
Slot 1	I1-0083	not executing/executing
	I1-0084	no error/error
Slot 2	I1-0085	not executing/executing
	I1-0086	no error/error
Slot 3	I1-0087	not executing/executing
	I1-0088	no error/error
Slot 4	I1-0089	not executing/executing
	I1-0090	no error/error
Slot 5	I1-0091	not executing/executing
	I1-0092	no error/error
Slot 6	I1-0093	not executing/executing
	I1-0094	no error/error
Slot 7	I1-0095	not executing/executing
	I1-0096	no error/error

I1-0209 through I1-464 - These contacts provide a "node active" map for slot 0/Serial Bus Address 0 through slot 7/Serial Bus Address 31.

I1-0209 indicates status for slot 0, SBA 0

. . .
 . . .
 . . .

I1-0464 indicates status for slot 7, SBA 31

GFK-0248

This chapter lists problems that might occur in a Series Five PLC system with a Genius Bus Controller, and suggests corrective actions you can take.

Errors are most likely when a new system is being started up. They are often caused by mistakes in cabling or field wiring, or by faulty logic in the CPU's application program. If problems occur, consult the troubleshooting information in this chapter. It will help you isolate any problem that originates in a Bus Controller. If these steps do not pinpoint the problem, the cause may lie in the CPU or programmer. You should refer to chapter 5 of the *Series Five Programmable Controller User's Manual* (GFK-0122) for further troubleshooting information.

If you have questions that are not answered in this manual or in the other documentation for your system, contact your local authorized GE Fanuc distributor. After business hours, you may call the Programmable Control Emergency Service Number, (804) 978-5747 (DIAL COMM 8-227-5747). An automatic answering device will direct you to the home phone of one of our Programmable Control Service Personnel. Thus, you are never without backup help.

How to Begin

- Check the operating mode of the CPU and, if appropriate, the programmer.
- Check the status LEDs on the CPU.
 - If some of the CPU status LEDs are off, refer to the *Series Five User's Manual*.
 - If all the CPU status LEDs are on but either of the Bus Controller LEDs is not, refer to the troubleshooting information on the following pages.
 - If all the CPU and Bus Controller LEDs are on, check cabling then proceed to I/O block troubleshooting. Refer to the *Genius I/O System User's Manual*.

Identifying the Problem

If a problem occurs, look for a description of the problem in the list that begins below. Then, refer to the troubleshooting suggestion with the same number on the pages that follow.

1. Both Bus Controller LEDs are off.
2. The Bus Controller BOARD OK LED is off and the COMM OK LED is on.
3. The BOARD OK LED is on and the COMM OK LED is off.
4. The BOARD OK and COMM OK LEDs are flashing in unison.
5. The Bus Controller is not communicating with the CPU. Intermittent or total lack of communications. No input data at CPU. No output data at block.
6. RD/WR CCM (Genius) and TRANSFER commands to the Bus Controller cause a syntax error.
7. RD/WR CCM (Genius) and TRANSFER commands to the Bus Controller don't show any status change.
8. The Bus Controller is not communicating on the Genius I/O serial bus.
9. The Bus Controller begins operating, but does not seem to be operating normally.
10. There are no functioning circuits on one bus, but other busses are working.
11. There are no functioning circuits on more than one bus.

12. The CPU system shuts down with parity errors after operating for a short time, or after changing the system configuration.
13. Communications on the bus are intermittent or lacking.
14. One of the following occurs:
 - a. The Bus Controller COMM OK light flashes excessively.
 - b. There are delays on the bus.
 - c. Addition of Block/Loss of Block diagnostics occur repeatedly although no blocks are actually being added or removed.

Problems 1 - 4

1. Both Bus Controller LEDs are off.
 - The Bus Controller is probably not receiving enough power from the rack or the power supply. Be sure the board is seated properly.
 - Replace the Bus Controller module.
2. The Bus Controller BOARD OK LED is off and the COMM OK LED is on.
 - Be sure the Bus Controller is installed in the correct slot.
 - Be sure the Serial Bus Address is set properly with the DIP switches on the Bus Controller.
 - Reseat the board.
 - Replace the Bus Controller module.
3. The BOARD OK LED is on and the COMM OK LED is off or blinking.
 - Check for correct cable type and length.
 - Check for correct terminating impedance at both ends of the bus.
 - Be sure the cable is daisy-chained.
 - Be sure wires to the Serial 1 and Serial 2 terminals are not crossed.
 - Look for a broken cable.
4. The BOARD OK LED and COMM OK LEDs are flashing in unison.
 - The Bus Controller detects another device on the same bus using the same Serial Bus Address. Change the Serial Bus Address of one of the two.

Problems 5 - 8

5. The Bus Controller is not communicating with the CPU.
 - This may indicate a programming or address assignment error. Also, check the CPU operating mode. Check particularly for overlapping addresses with other modules in the CPU base unit. This includes blocks controlled by other Bus Controllers in the CPU base unit.
6. RD/WR CCM and TRANSFER commands to the Bus Controller cause a syntax error.
 - Check the command format.
7. RD/WR CCM and TRANSFER commands to the Bus Controller don't show any status change.
 - A command is being sent to a non-existent Bus Controller. Power flows through the RDCCM or WRCCM instruction, but the status doesn't change.

GFK-0248

8. The Bus Controller is not communicating on the Genius I/O serial bus.
 - Two devices on the same bus may have been configured with the same Device Number. Check this using the Hand-Held Monitor. Note that a Phase B Bus Controller will not communicate on a bus if its assigned Device Number is already used by another device. However, both the Unit OK and the COMM OK LEDs will be blinking together.
 - Be sure wires to the Serial 1/Serial 2 terminals on the module are not crossed or shorted together or to ground.
 - Check the baud rate.
 - Check the Device Number (serial bus address) assigned to the Bus Controller against the intended Device Number from your records of system configuration. New Bus Controllers are shipped from the factory already set up to use Device Number 31.
 - Use the HHM to compare Device Numbers and Reference Numbers.
 - Check the Bus Controller's Outputs Disabled bits using Read Configuration command to the Bus Controller. Also check Bus Controller output #1 (Disable All Outputs).

Problems 9 - 12

9. The Bus Controller begins operating, but does not seem to be operating normally.
 - Be sure serial bus wiring has been completed in a daisy chain fashion.
 - Make sure the communications cable is not close to high voltage wiring.
 - Look for a broken cable. Check for intermittent cable breaks and connections.
 - Ensure that cable shielding is properly installed and grounded (see chapter 6 of the *Genius I/O System User's Manual*).
10. There are no functioning circuits on one bus, but other busses are operating normally.
 - From the CPU, see if the Bus Controller has its Outputs Disabled. This selectable feature allows a module to receive inputs, but not to send outputs. See chapter 4 for more information.
 - Check to see if the Bus Controller is properly installed, seated properly, and receiving power.
 - Check the on-board DIP switches.
 - Pull out the Bus Controller and reinsert.
 - Check for loose communications cable connections or breakage.
 - If necessary, replace the Bus Controller.
11. There are no functioning circuits on more than one bus.
 - Refer to Chapter 5 of the Series Five User's manual for troubleshooting information.
12. The CPU system shuts down with parity errors after operating for a short time, or after changing the system configuration.
 - There may be duplicate or overlapping I/O references coming from different busses.
 - Unplug one Bus Controller, refer to the configuration worksheets, and use the HHM to read Reference Numbers. If necessary, check other buses the same way.
 - Verify that no conventional I/O module has reference numbers that overlap references assigned to Genius I/O devices.

Problems 13 - 14**13. Communications on the bus are intermittent or lacking.**

- This may be caused by mixed baud rates. To check this, power up blocks one at a time and look at their respective baud rates using the HHM. If you find different baud rates, they must be changed. All devices on the bus must use the same baud rate. *Any change to baud rates in blocks will not take effect until block power is cycled.*
- For Phase A devices, check for duplicate Block Numbers. Power devices up one at a time and confirm Block Numbers using the HHM.
- The terminating resistors on the bus may be missing or incorrectly chosen or placed. Check terminators at ends of the bus for correct resistance value. BSM cluster "stubs" should not be terminated.
- The cable may be too long. Shorten the cable or configure all devices on the bus to use a lower baud rate. Refer to chapter 5 of the *Genius I/O System User's Manual* for more information about cabling and baud rate selection.
- Wires may be open, shorted, or reversed. Check all bus electrical connections.

14. The COMM OK light on the Bus Controller blinks excessively, and/or there are propagation delays on the bus, and/or the bus is operating, but the CPU repeatedly receives Addition of Block and/or Loss of Block diagnostics.

- There is excessive ambient noise on the bus. This can be corrected by lowering the baud rate, rerouting the communications cable, or shielding the source of the electrical noise. The proper solution to these problems will depend on the application. Refer to chapter 5 of the *Genius I/O System User's Manual* for information on cabling, baud rates, and ambient electrical noise.

Appendix A

Diagnostic Information

Bus Controller Diagnostic Information

The Bus Controller provides the user with a powerful tool through an extensive set of diagnostics reported to the CPU. The Bus Controller sends diagnostic reports to the CPU, which provide Bus Controller status, and serial bus status. It also sends diagnostic messages from Genius I/O blocks on the serial bus. These messages provide an indication of block and individual I/O circuit faults. Once it is received by the CPU, this diagnostic information is available to the ladder logic program.

Diagnostic information from the CPU can be displayed on a CRT using Logicmaster™ 5 software.

Default Genius I/O Diagnostic Fault Configuration

The default configuration for Genius I/O diagnostic fault data reported by the Bus Controller to the CPU, is that this data is stored in a reserved group of data registers, R3850 through R3999, which is referred to as the Genius I/O fault table. Certain parameters for the fault table are stored in registers R4049, R4050, and R4051 (refer to chapter 6). The CPU initializes this fault table only if the user has enabled the Genius I/O Diagnostics function using Logicmaster 5, and has not changed the default parameters.

Since the reserved registers can be accessed by the CPU, Logicmaster 5, the Operator Interface Unit, and user logic, care must be taken to ensure that user logic does not overwrite these registers when the Genius I/O Diagnostics function is enabled.

The default Genius I/O Fault Table can record a maximum of 15 faults, with each fault using 10 registers. The information recorded in these registers is interpreted by Logicmaster 5 and displayed in the GENIUS I/O FAULT TABLE screen on the programming device.

Registers for Default Configuration

Ten registers are reserved for recording each of the 15 faults. The first fault is recorded in registers 3850 through 3859, the second in registers 3860 through 3869, through to the fifteenth fault being recorded in registers 3990 through 3999. *The registers which comprise the default configuration for the fault table are shown below.*

Start of Table	R4049									
Length of Table	R4050									
Number of Faults	R4051									
Fault 1 Data	R3850	R3851	R3852	R3853	R3854	R3855	R3856	R3857	R3858	R3859
Fault 2 Data	R3860	R3861	R3862	R3863	R3864	R3865	R3866	R3867	R3868	R3869
Fault 3 Data	R3870	R3871	R3872	R3873	R3874	R3875	R3876	R3877	R3878	R3879
Fault 4 Data	R3880	R3881	R3882	R3883	R3884	R3885	R3886	R3887	R3888	R3889
Fault 5 Data	R3890	R3891	R3892	R3893	R3894	R3895	R3896	R3897	R3898	R3899
Fault 6 Data	R3900	R3901	R3902	R3903	R3904	R3905	R3906	R3907	R3908	R3909
Fault 7 Data	R3910	R3911	R3912	R3913	R3914	R3915	R3916	R3917	R3918	R3919
Fault 8 Data	R3920	R3921	R3922	R3923	R3924	R3925	R3926	R3927	R3928	R3929
Fault 9 Data	R3930	R3931	R3932	R3933	R3934	R3935	R3936	R3937	R3938	R3939
Fault 10 Data	R3940	R3941	R3942	R3943	R3944	R3945	R3946	R3947	R3948	R3949
Fault 11 Data	R3950	R3951	R3952	R3953	R3954	R3955	R3956	R3957	R3958	R3959
Fault 12 Data	R3960	R3961	R3962	R3963	R3964	R3965	R3966	R3967	R3968	R3969
Fault 13 Data	R3970	R3971	R3972	R3973	R3974	R3975	R3976	R3977	R3978	R3979
Fault 14 Data	R3980	R3981	R3982	R3983	R3984	R3985	R3986	R3987	R3988	R3989
Fault 15 Data	R3990	R3991	R3992	R3993	R3994	R3995	R3996	R3997	R3998	R3999

Fault Register	\ 1	2	3	4 /	\ 5	6	7 /	\ 8	9	10 /
Content of Registers	I/O Address				Category Type Description			Time Stamp		

Data Entered in Fault Tables

The CPU records information for each fault in registers as shown above. The I/O address where the fault was detected is recorded in registers 1 through 4 of each fault table entry. Fault category, type of fault, and fault description are recorded in registers 5 through 7 of each fault table entry.

The time stamp of when the fault was detected is recorded in registers 8 through 10 of each fault table entry. Each bit, unless cleared, in the registers contains useful information as shown below.

I/O Address - Registers 1 Through 4

The I/O address, where the fault occurred is stored in registers 1 through 4.

Register	Bits	Address Data
1	00 - 02	Slot number of the Bus Controller reporting the fault (valid range 0 - 7).
	03 - 15	Unused, set to logic 0
2	00 - 09	I/O address of failed point (valid range 1 - 1024)
	10	Input point block fault
	11	Output point block fault
	12 - 15	I/O channel (valid, 1 or 2)
3	00 - 03	Circuit or analog channel offset (valid range (0 - 15)
	04 - 15	Unused, set to logic 0
4	00 - 15	Unused, set to logic 0

GFK-0248

Fault Category - Register 5

The fault category is stored in register 5, bits 8 through 13.

Bit Fault Category

- 8 Genius Bus Controller fault - Indicates a Bus Controller module failure.
During the Bus Controller service routine the CPU reads the Board OK byte in the Bus Controller status table. This check is even made if diagnostics are not enabled. If the byte is not equal to one then a Bus Controller fault exists. The CPU will discontinue service to this Bus Controller until the Board OK byte is a one. Once this error has been reported in the fault table, another fault table entry for this same error is not generated unless one of the following conditions occur:
- Power Cycle
 - Stop to Run transition
 - Board OK bit goes to a one (OK) and then to a zero again.
- 9 Serial Bus Error - Excessive bus communications errors are occurring.
If more than ten bus communications errors occur during a ten seconds period, the CPU will report a Bus Error fault (if diagnostics are enabled). The Bus Controller provides an indication of excessive bus errors in byte 3, bit 2 of the interrupt status table (address 0895H). If this bit is a one, then a bus error should be reported (if diagnostics are enabled). Once a bus error has been reported, the error should not be reported again unless the bit transitions to a zero and then to a one again.
- 10 Circuit Fault - Genius I/O block point or channel problem.
- 11 Loss of Module - A device has logged out.
- 12 Addition of Module - A device has logged in with no address conflict.
- 13 Address Conflict - A device has logged in that conflicts with a device already on the bus. The CPU is not communicating with this device. Its input data is not being transferred to the I1+ tables, and the output disabled bit in the bus controller's shared RAM is set to inhibit transmission of O+ table data to the device.
- 14 EEPROM Failure

Fault Type - Register 6

A value in bits 0 through 3 of register 6 contain a value which represents the possible fault type.

Value	Fault Type
0000	Block Headend Fault
0001	Discrete (circuit number, range 1 - 16)
0010	Analog Circuit
0011	Reserved for future use
0100	Analog (thermocouple, RTD, strain gauge)
1001	Discrete (circuit number, range 17 - 32)

Fault Description - Registers 5, 6, 7

The fault description is stored in registers 5, 6, and 7. The registers, bits used, and definitions are based on the fault type as defined in register 6, bits 0 through 3.

Fault Type 0000 - The fault description for the block type is recorded by setting the appropriate bit of register 5.

Bit	Fault Description
6	Calibration Data Lost
7	Shared RAM
8	Internal Circuit Fault

Fault Type 0001 - The fault descriptions for discrete points 1 - 16 are recorded by setting one or more bits in the high byte of register 6.

Bit	Fault Description
8	Loss of I/O Power (Isolated block only)
9	Short Circuit
10	Overload
11	No Load (if output), Open Wire (if input)
12	Over Temp
13	Switch Failed

Fault Type 0010 - Descriptions for analog type faults are recorded by setting one or more bits in the low byte of register 7.

Bit	Fault Description
0	Input Low Alarm
1	Input High Alarm
2	Input Underrange
3	Input Overrange
4	Input Open Wire
5	Output Underrange
6	Output Overrange
7	Reserved

Fault Type 0011 - Reserved for future use.

Fault Type 0100 - The descriptions for low level analog input-only block faults are recorded by setting one or more bits in the low byte of register 5.

Bit	Fault Description
0	Input Low Alarm
1	Input High Alarm
2	Input Underrange
3	Input Overrange
4	Input Open Wire
5	Input Wiring Error
6	Internal Channel Fault
7	Input Channel Short

GFK-0248

Fault Type 1001 - The fault descriptions for discrete points 17 - 32 are recorded by setting one or more bits in the low byte of register 5.

Bit	Fault Description
1	Short Circuit
2	Overload
3	No Load (if output), Open Wire (if input)
4	Over Temp
5	Switch Failed

Time Stamp

The CPU records the time and date that the fault was captured in registers 8, 9, and 10 of the fault table entry. This information is available from registers 4087 through 4093.

Register	Bits	Description	Range Of Value
8	0 - 7	Seconds	00 through 59
	8 - 15	Minutes	00 through 59
9	0 - 7	Hours	00 through 23
	8 - 15	Day	01 through 31
10	0 - 17	Month	01 through 12
	8 - 15	Year	00 through 99

Appendix B

Scratch Pad Memory Map for Genius Bus Controller Setup Parameters

The Genius Bus Controller setup parameters are stored in an area of Scratch Pad memory from 256H to 2B5H. The parameters for each CPU base unit slot that may contain a Bus Controller are stored in twelve consecutive bytes, starting with slot 0 in Scratch Pad memory location 256H, and continuing consecutively through slot 7. The format for the parameters for each slot is shown in the following table.

Scratch Pad Location	Content
Offset + 0 (1)	Slot Number
1	Serial Bus Address
2	Reference Address (LSB) * (2)
3	Reference Address (MSB) *
4	Broadcast Data Length (Bytes) *
5	Directed Data Length (Bytes) *
6	Baud Rate
7	- Not Used -
8	Output Enables for SBA 7 to 0 *
9	Output Enables for SBA 15 to 8 *
A	Output Enables for SBA 23 to 16 *
B	Output Enables for SBA 31 to 24 *

(1) Offset = 256H + (slot number x 0CH).

(2) Only locations with an * next to them are written by Logicmaster 5 or the OIU to Scratch Pad memory.

Appendix C

Datagram Transmission Between Series Five and Series Six PLCs

Since the Series Five PLC has the capability to pass Genius Global Data over a Genius bus with very little setup, sending datagrams between CPUs is often not necessary. If datagram transfers are required between two or more Series Five CPUs, the commands RDCCM (Read CCM) and WR CCM (Write CCM) should be used. These commands are simple and require little code. Refer to Chapter 5 in this manual for details on these commands. It is still a simple transmission if the Series Six CPU or PCIM (IBM PC Interface Module) wants to initiate a datagram to the Series Five CPU. However if the Series Five CPU must initiate a datagram to a Series Six CPU or the PCIM, then the TRANSFER command must be used.

The TRANSFER command is easy to use but requires a lot of preloading of registers containing the datagram information. This application note gives a brief explanation of the TRANSFER instruction, register definition and setup, and an example of relay ladder logic needed to send a datagram to a Series Six requesting register data to be sent to the Series Five. Also included is a description of the information necessary for a Series Six CPU or PCIM to request data from the Series Five CPU.

The Series Five CPU and smart module memory is divided into areas called segments. Each slot in the rack is assigned a segment number. Within each segment there is an offset that starts at 0 and identifies the specific location within a segment. The upper address is a segment number and the lower address is an offset. The segment of memory where all Series Five CPU and smart module RAM resides is in the 8000H area; the exact location being determined by the slot in which the module is installed. The CPU is always in the CPU slot and its segment address is 8005H. The segment addresses for the rest of the slots are: 8006H for slot 0 through 800DH for slot 7.

The lower address is the offset within the segment. The offsets for areas in the Series Five Genius Bus Controller module are listed below:

Offset	Name	Description
0882 - 0891	Setup Table	Genius Bus Controller configuration parameters
0892 - 08A1	Status Table	Bus status information
08C2	Command	Genius Bus Controller execution command code
08C3 - 08D1	Command Block	Datagram command field
08D2 - 09C1	Output Area	Datagram data field for Transmit commands
09C2 - 0A47	Input Area	Information from incoming datagrams stored here
1E00 - 1EFF	Device Config	Table containing bus configuration data

The offsets for the CPU must be calculated based on the starting memory address of the register and I/O structures. For example the starting offset address of Series Five register memory is 0. The following procedure can be used to determine the offset for a specific location in register memory. This example uses register 200.

$((\text{Register Number}) - 1) \times 2 = \text{Decimal offset.}$

Convert Decimal offset to hexadecimal and add to starting offset address.

Example - Calculating register 200 offset address

$((200) - 1) \times 2 = 398 + 0 = 18\text{EH}$

The segment and offset memory map for the Series Five CPU is shown below:

Reference	Memory Map			
	Segment	Offset	Segment	Offset
R1 - R16384	8005H	0000H	-	8005H 7FFFH
I1+0001 - I1+1024	8005H	8000H	-	8005H 807FH
I2+0001 - I2+1024	8005H	8080H	-	8005H 80FFH
O1+0001 - O1+1024	8005H	8100H	-	8005H 817FH
O2+0001 - O2+1024	8005H	8180H	-	8005H 81FFH
I0001 - I1024	8005H	8200H	-	8005H 827FH
O0001 - O1024	8005H	8280H	-	8005H 82FFH
O1-0001 - O1-1024	8005H	8300H	-	8005H 837FH
O2-0001 - O2-1024	8005H	8380H	-	8005H 83FFH
I1-0001 - I1-0512	8005H	8500H	-	8005H 853FH

Datagram Format

If the Series Six CPU or PCIM wants data from the Series Five CPU, a datagram must be sent. The formats for datagrams are discussed in GEK-90486, the Genius I/O System User's Manual, and GFK-0074, the Genius I/O PCIM User's Manual. In the datagram the target address is the Series Five CPU memory. The data for that address is shown below:

TARGET ADDRESS			
00	85	OFFSET MSB	OFFSET LSB

The upper two bytes are always the same; the lower two bytes are the actual location in memory of the desired data. This type of transmission would not require any programming in the Series Five. The movement of data in and out of memory locations would be totally handled by the Series Five CPU and Genius Bus Controller as a background task.

GFK-0248

The TRANSFER Command

For the Series Five CPU to request data from a Series Six CPU or PCIM, a TRANSFER command must be used in the Series Five relay ladder diagram to initiate a datagram and send it via the Series Five Genius Bus Controller. The TRANSFER command sends a predefined amount of data from one memory location to another. It does not perform the actual datagram sending or receiving. The transfer command takes the datagram command programmed in the CPU and sends it to the Genius Bus Controller for action or vice versa. The TRANSFER command has one parameter; a register. This register is the first register in a string of five consecutive registers that contain the source address, destination address, and number of bytes to be transferred. The format is shown below:

Register (X)	Upper	Source
Register (X+1)	Lower	Source
Register (X+2)	Upper	Target
Register (X+3)	Lower	Target
Register (X+4)		Length

To generate a datagram requires a minimum of three TRANSFER instructions.

1. The first TRANSFER command sends the datagram command to the Genius Bus Controller.
2. The second command sends the data associated with the datagram to the Genius Bus Controller.
3. The third TRANSFER sends a command to the Genius Bus Controller to execute the datagram.

A description of the datagram can be found in the Genius I/O System User's Manual, or the Genius I/O PCIM User's Manual. The data must be placed into consecutive bytes. This is easily done by loading the datagram information into consecutive registers. The source address would be the absolute address of the first register with the datagram information. The target address would be an absolute address in the Genius Bus Controller and the number of bytes would be the number of command or data bytes. The third TRANSFER command sends a signal to the Genius Bus Controller to execute the datagram.

Once the datagram is generated, a TRANSFER command must be used to check the status of the datagram; if data is being received by the Series Five, another TRANSFER command is needed to send the data to the CPU memory. A minimum of 4 TRANSFER instructions is needed to complete communications. A fifth TRANSFER command is needed *only* if data is coming into the Series Five.

Sending Datagrams - Series Five PLC to Series Six PLC

The following example demonstrates how a Series Five PLC sends a datagram to a Series Six PLC requesting that register information be sent back to the Series Five. In this example, the Series Five wants data in Series Six registers 1 through 10 stored in Series Five registers 240 through 249. This requires a minimum of five TRANSFER commands. To do this, registers must first be assigned for the TRANSFER command parameters and for the datagram information in the Series Five. Assignments for this example are as follows:

Registers	Contents
200 - 209	datagram command
210 - 219	datagram data
220	command to Genius Bus Controller to perform datagram
230	status code
240 - 249	Series Six data received
300 - 309	parameters for first TRANSFER command
310 - 319	parameters for second TRANSFER command
320 - 329	parameters for third TRANSFER command
330 - 339	parameters for fourth TRANSFER command
340 - 349	parameters for fifth TRANSFER command

In order for the Series Five PLC to receive data from the Series Six a READ DEVICE REPLY datagram is used. The datagram command is loaded into registers 200 through 209; the format is shown below:

Register	MSB	LSB
200	Destination Serial Bus address	Transfer command code
201	Transmitted reply sub-function code	Function code
202	Priority	Expected reply sub-function code
203	Always 0	Data field length

The TRANSFER COMMAND CODE tells the Series Five Genius Bus Controller what type of datagram it is going to execute. The following values define the various types of datagrams:

- 1 - READ DATAGRAM
- 2 - TRANSMIT DATAGRAM
- 3 - TRANSMIT DATAGRAM WITH REPLY

The information after the TRANSFER COMMAND CODE is the basic datagram command. The actual hexadecimal codes in registers 200 - 209 are:

Register	MSB	LSB
200	1F	03
201	1E	20
202	00	1F
203	00	06

GFK-0248

Registers 204 through 209 are not used in this example. Registers 210 through 219 contain the data fields or address areas for the actual transfer. The format for the address area is shown below:

Register	MSB	LSB
210	LSB of source address	Always 0
211	LSB of destination address	MSB of source address
212	Number of bytes to transfer	MSB of destination address

In this example program the source address is the absolute address of the register memory in the Series Six PLC that is to be sent to the Series Five PLC. The destination address is the location in the Series Five PLC where the data will be transferred. This address will always be the same for the Series Five PLC; 8000H. The address is actually a control code that identifies the destination as a Series Five PLC. In the example program, the actual hexadecimal codes in registers 210 through 219 are shown below:

Register	MSB	LSB
210	00	00
211	00	40
212	14	80

Registers 213 through 219 are not used in this example. The last information that will get transferred to the Series Five Genius Bus Controller is the signal for the Genius Bus Controller to perform the datagram. A value of 1 transferred to the Genius Bus Controller after all the datagram information has been sent will cause execution of the datagram. For this example a value of 1 is placed in register 220.

After all the information about the datagram is set up in registers, the data must be transferred to the Genius Bus Controller. This is where the actual TRANSFER command comes in. The first TRANSFER sends the bus datagram command to the Genius Bus Controller. The source starting address is register 200 and the destination address is the Command Block area of the Genius Bus Controller. The length of the datagram information stored starting in register 200 is 7 bytes. Starting in register 300, the following information is stored:

Register	MSB	LSB
300	80	05
301	01	8E
302	80	06
303	08	C3
304	00	07

The second TRANSFER command sends the data field of the datagram to the Genius Bus Controller. The source address for the data field is register 210 and the destination address is the Output Area. The length of the data field is stored in six bytes starting at register 210. The TRANSFER command data starting in register 310 is listed below:

Register	MSB	LSB
310	80	05
311	01	A2
312	80	06
313	08	D2

The third TRANSFER command sends the command to perform the datagram. The source address for the command is in register 220 and the destination address is the command byte in the Genius Bus Controller. The length of the command is one byte. The TRANSFER command data, starting in register 320, is listed below:

Register	MSB	LSB
320	80	05
321	01	B6
322	80	06
323	08	C2
324	00	01

The datagram has now been sent to the Series Six. Now the Series Five PLC must wait for a reply. To find out if a reply has been sent, the CPU must monitor the Genius Bus Controller. The Command byte contains the status in the Genius Bus Controller. If the Command byte contains a value of 4, the datagram was successful. However, if it contains a value of 8 or 10, the datagram must be sent again. To get this Command byte, the CPU must perform another TRANSFER command. In this example the status will be put into register 230. This means that the source address is the Genius Bus Controller Command byte and the destination address is register 230. The length is 1 byte. Following is the TRANSFER command data starting in register 330:

Register	MSB	LSB
330	80	06
331	08	C2
332	80	05
333	01	CA
334	00	01

GFK-0248

After verifying that the datagram has successfully transferred, the register data sent from the Series Six PLC to the Series Five PLC must be transferred from the Genius Bus Controller to the CPU. This is the final TRANSFER command needed. The source address is the Input Area in the Genius Bus Controller and the destination address is register 240. The length is 20 bytes since the Series Six PLC sent data from 10 registers. The TRANSFER command data starts in register 340 and is shown below:

Register	MSB	LSB
340	80	06
341	09	C2
342	80	05
343	01	DE
344	00	14

Relay Ladder Diagram Example

This example described above is shown in the following relay ladder diagram.

```
<< RUNG    0 >>
```

This program has the Series Five ask for Registers 1-10 in the Series Six to be sent over via the Genius LAN. It shows the correct use of the TRANSFER command in the Series Five to execute a Genius datagram command.

```
+ [ Start of Program ] -
```

```
<< RUNG    1 >>
```

The first 8 rungs gets the datagram and TRANSFER command data into register memory. For testing purposes Input 1 is used to initiate the block moves.

Rung 1 - Sets up the datagram command codes.

```

I0001  R00200
+---] [---[                                BLOCK MOVE                                ]- ( )
                                +07939 +07712 +00031 +00006 +00000 +00000 +00000

```

```
<< RUNG    2 >>
```

Rung 2 - Sets up the data field of the datagram command.

```

I0001  R00210
+---] [---[                                BLOCK MOVE                                ]- ( )
                                +00000 +00064 +05248 +00000 +00000 +00000 +00000

```

GPK-0248

<< RUNG 3 >>

Rung 3 - Sets up the GO command for the Genius Bus Controller.

I0001 R00220

```
+++] [---[                                BLOCK MOVE                                ]- ( )
                                +00001 +00000 +00000 +00000 +00000 +00000 +00000
```

<< RUNG 4 >>

Rung 4 - Sets up the first TRANSFER command to get the datagram command to the Genius Bus Controller.

I0001 R00300

```
+++] [---[                                BLOCK MOVE                                ]- ( )
                                -32763 +00398 -32762 +02243 +00007 +00000 +00000
```

<< RUNG 5 >>

Rung 5 - Sets up the second TRANSFER command to get the data field of the datagram over to the Genius Bus Controller.

I0001 R00310

```
+++] [---[                                BLOCK MOVE                                ]- ( )
                                -32763 +00418 -32762 +02258 +00006 +00000 +00000
```

<< RUNG 6 >>

Rung 6 - Sets up the TRANSFER command to send over the command to the Genius Bus Controller to execute the datagram.

I0001 R00320

```
+++] [---[                                BLOCK MOVE                                ]- ( )
                                -32763 +00438 -32762 +02242 +00001 +00000 +00000
```

<< RUNG 7 >>

Rung 7 - Sets up the TRANSFER command to continually poll the status of the Genius Bus Controller for completion of the datagram.

```

I0001  R00330
+---] [---[          BLOCK MOVE          ]- ( )
                -32762 +02242 -32763 +00458 +00001 +00000 +00000

```

<< RUNG 8 >>

Rung 8 - Sets up the TRANSFER command to get the data sent from the Series Six to the Genius Bus Controller of the Series Five into the Series Five CPU.

```

I0001  R00340
+---] [---[          BLOCK MOVE          ]- ( )
                -32762 +02498 -32763 +00478 +00020 +00000 +00000

```

<< RUNG 9 >>

This rung causes Output 2 to turn on once when Input 2 turns on which causes the first 3 TRANSFER commands to execute. After the third TRANSFER command, the datagram from the Series Five to the Series Six is executed.

```

I0002                                     O0002
+---] [-----]----- (OS)

```

<< RUNG 10 >>

```

O0002          R00300
+---] [---[ TRANSFER ]- ( )

```

GFK-0248

```
<< RUNG    11 >>
O0002      R00310
+---] [---[ TRANSFER ]- ( )
```

```
<< RUNG    12 >>
O0002      R00320
+---] [---[ TRANSFER ]- ( )
```

```
<< RUNG    13 >>
```

After the datagram is sent, as long as Input 2 is on, the Series Five CPU will continue to poll the Genius Bus Controller for completion of the datagram.

```
I0002      R00330
+---] [---[ TRANSFER ]- ( )
```

```
<< RUNG    14 >>
```

Once the status of the Genius Bus Controller command byte equals 4, Output 1 is turned on to cause a TRANSFER, which puts the data sent from the Series Six to the Series Five Genius Bus Controller into the register memory of the Series Five CPU.

```
Const R00230 O0001
+[ A EQUAL B ]----- ( )
+00004
```

```
<< RUNG    15 >>
```

```
O0001      R00340
+---] [---+ TRANSFER ]- ( )
```

```
I0003
+---] [---+
```


```
<< RUNG    16 >>
```

```
+ [ENDSW]-
```


Appendix D

Switch BSM Datagram Command From a Series Five PLC

This appendix provides an example of sending a BSM (Genius I/O Bus Switching Module) switch command from a Series Five PLC.



Set registers as follows prior to execution of the above logic:

Register	Data	Definition
R200	1F02H	Byte 1 = target SBA, byte 2 = 02H (send datagram)
R201	1C20H	Byte 1 = Subfunction code for switch BSM, byte 2 = 20 (PLC)
R202	0100H	Byte 1 = data length, byte 2 = priority
R210	0000H 0001H	(for Bus A) This is the datagram data field (for Bus B)
R220	0001H	1 = the GBC "go command" to send the datagram
R300	8005H	From S5 register
R301	018EH	200 -- this number is $(200-1)*2 = 398$ decimal.
R302	8006H	To the GBC in slot 0 (MSB=80H, LSB = slot number of GBC + 6),
R303	08C3H	at address 8C3 of the GBC,
R304	0006H	Move 6 bytes, in this case R200 thru R202.
R310	8005H	From S5 register
R311	01A2H	210 -- this number is $(210-1)*2 = 418$ decimal.
R312	8006H	To the GBC in slot 0 (MSB=80H, LSB = slot number of GBC + 6),
R313	08D2H	at address 8D2H of the GBC,

Register	Data	Definition
R314	0001H	Move the contents of the LSB (1 byte) of R210.
R320	8005H	From S5 Register
R321	01B6H	220 – this number is $(220-1)*2 = 438$ decimal.
R322	8006H	To the GBC in slot 0 (MSB=80H, LSB = slot number of GBC + 6),
R323	08C2H	at address 8C2H of the GBC,
R324	0001H	Move the contents of the LSB (1 byte) of R220.
R330	8006H	From GBC in slot 0,
R331	08C2H	GBC address 8C2H,
R332	8005H	To S5 Register
R333	029CH	335 (this number is $(335-1)*2 = 668$ decimal.
R334	0002H	Move the contents of 2 bytes (this is the busy status of the GBC)

Appendix E

Setup Differences Based on CPU Revisions

The setup procedure for the Genius network is quite different depending on the CPU revision level. For revision B CPUs, it was NOT necessary to configure global data, but it WAS necessary to enable the output bits on a node by node basis.

On revision C or later CPUs, it IS necessary to configure global data, but the output enable bits default to the on state, which is more convenient for setup with blocks. Details of the setup procedure for revision C CPUs and later are covered below.

Compatibilities

To operate properly with the Genius network, you need the following:

- Series Five CPU revision B or later; revision 3.0/2.X or later, (revision D or later is recommended);
- Series Five Genius Bus Controller revision B or later;
- Genius Hand-Held monitor version 3.2 or later;
- Logicmaster 5 version 2.01 or later.

If you do not have the above revisions, parts or all of your Genius related configuration will not work properly.

Restrictions

With the version 3.0 CPU, you cannot have Genius diagnostics enabled at the same time as RD CCM and WR CCM are active with the Genius Bus Controller. In addition, with this CPU, the Genius Bus Controller worked properly only in slot 0. For this reason, revision D or later is recommended.

A CPU firmware upgrade kit IC655UPG500 is available to bring your CPU firmware to the latest revision.

Also, you can never have phase A Genius blocks in a system where ANY Genius phase B features are to be used. This means that if you have phase A blocks in a system, you cannot use the following:

- Global Data
- Baud rates other than 153.6K
- Redundancy
- Multiple controllers on the same bus
- Datagrams (including RD CCM, WR CCM functions)

If you want to use phase A blocks, you must not attempt to use the above features. This restriction is not related to version levels of the CPU, or any other device, this is a Genius I/O system limitation.

Differences in Operation Between CPU Revision B and Later Revision CPUs

The revision B CPU defaults to the following states:

- RD/WR CCM allowed (low priority S5 to S5);
- Global Data status table address set in register table, address depending on the serial bus address assigned to the controller (in the range of R0017 to R0080);
- Global data length set to 8 registers (enabled global data from R17-80);
- Serial bus address output enable bits set to disabled;

This allowed automatic operation of global data with no end user interaction, but was inconvenient when using blocks.

The revision B CPU has been replaced with revision D and will not be described further. **All further discussion assumes a revision D CPU or later.**

Later revision CPUs default to the following states:

- RD/WR CCM allowed (Low priority S5 to S5);
- Global data address set to 0 (disables global data);
- Global data length set to 0 (disables global data);
- Serial bus address output enable bits set to enabled.

This allows easier setup with Genius blocks, but requires you to establish setup parameters for global data if this function is desired. These defaults disable the automatic overwriting of registers R17 to R80 which occurred in the revision B CPU.

GFK-0248

A

Address Conflict, 5-6

B

BSM Datagram Example, D-1
Bus Controller Description, 1-2
Bus Controller Diagnostic Information, A-1
Bus Controller Installation and
Configuration, 3-1
Bus Controller Setup Key Summary, 3-10

C

Changing the Global Data Setup, 3-8
Clear All Faults and Pulse Test Function, 5-5
Combining Global Data Communications and
I/O Control, 2-5
Command, TRANSFER, C-1
Command, TRANSFER, Ladder Logic, C-8
Configuration Parameters for Global Data
Communications, 3-9
Contents of Fault Table, 5-2

D

Data Entered in Fault Tables, A-2
Datagram Example, Between Series
Five/Six, C-1
Datagram Example, BSM, D-1
Datagram Format, C-2
Datagrams, 2-4
Default Genius I/O Diagnostic Fault
Configuration, A-1
Device Addition, 5-6
Device Loss, 5-6
Displaying the Bus Controller Setup
Screen, 3-9
Displaying the Genius I/O Diagnostics
Screen, 5-1
Dual Bus Redundancy, 2-5
Dual Controller Redundancy, 2-6

Duplex Redundancy Mode, 2-6

E

Editing GBC Setup Parameters With
Logicmaster 5 Software, 3-9
Example of Reading from a Remote CPU:, 4-3
Example of Writing to a Remote Series Five
PLC with a Genius Bus Controller., 4-3
Examples of Address Assignments, 3-6

F

Fault Category - Register 5, A-3
Fault Description - Registers 5, 6, 7, A-4
Fault Table Display, 5-2
Fault Type - Register 6, A-3

G

Genius I/O Block Setup Procedures, 3-5
Genius I/O Serial Bus, 2-1
Global Data and Transmit Data Lengths, 3-11
Global Data Communications, 2-5

H

Hot Standby Mode, 2-6

I

I/O Address - Registers 1 Through 4, A-2
Interfacing With Genius Networks, 2-3
Internal Coils, 5-4
Introduction, 2-1, 4-1, 5-1

L

Ladder Logic, TRANSFER Command, C-8
LEDs, 1-3, 6-1

O

Operation:, 4-2

P

Product Summary, 1-1

Purpose of the Genius Bus Controller, 1-2

R

Read/Write CCM, 4-2

Redundancy, 2-5

Reference Address, 3-11

Registers for Default Configuration, A-2

Related Publications, iii

Relay Ladder Logic for TRANSFER
Command, C-8

S

Selection of Serial Bus Address, 3-2

Selection of Serial Bus Baud Rate, 3-2

Sending Datagrams, Example of, C-4

Setting the Outputs Enable DIP Switch, 3-3

Setup Ranges, 3-10

Special Registers, 5-3

Special Registers, Contacts, and Coils for
Genius I/O Operation, 5-2

Starting Reference Address, 2-3

Supporting Genius Communications Between
CPUs, 2-4

Symbology:, 4-2

T

The Bus Scan, 2-2

The Serial Bus Address, 2-3

Time Stamp, A-5

TRANSFER Command, C-3

TRANSFER Command, Example of, C-1

TRANSFER Command, Relay Ladder
Logic, C-8

Troubleshooting, 6-1

Typical Genius I/O Bus, 2-2

U

Use of Read CCM and Write CCM to
Communicate with Other CPUs, 4-1

User Interface to Genius I/O Diagnostics, 5-1

Using a Bus Controller with Default Setup
Conditions, 3-3

Using Genius I/O with a Series Five PLC, 1-1

