

GFK-0823

[Buy GE Fanuc Series 90-30 NOW!](#)

GE Fanuc Manual Series 90-30

I/O Link Master Module

1-800-360-6802
sales@pdfsupply.com



GE Fanuc Automation

Programmable Control Products

Series 90TM-30 I/O Link Master Module

User's Manual

GFK0823A

July 1994

Warnings, Cautions, and Notes as Used in this Publication

Warning

Warning notices are used in this publication to emphasize that hazardous voltages, currents, temperatures, or other conditions that could cause personal injury exist in this equipment or may be associated with its use.

In situations where inattention could cause either personal injury or damage to equipment, a Warning notice is used.

Caution

Caution notices are used where equipment might be damaged if care is not taken.

Note

Notes merely call attention to information that is especially significant to understanding and operating the equipment.

This document is based on information available at the time of its publication. While efforts have been made to be accurate, the information contained herein does not purport to cover all details or variations in hardware or software, nor to provide for every possible contingency in connection with installation, operation, or maintenance. Features may be described herein which are not present in all hardware and software systems. GE Fanuc Automation assumes no obligation of notice to holders of this document with respect to changes subsequently made.

GE Fanuc Automation makes no representation or warranty, expressed, implied, or statutory with respect to, and assumes no responsibility for the accuracy, completeness, sufficiency, or usefulness of the information contained herein. No warranties of merchantability or fitness for purpose shall apply.

The following are trademarks of GE Fanuc Automation North America, Inc.

Alam Master	CIMSTAR	Helpmate	PROMACRO	Series Six
CIMPLICITY	GENet	Logicmaster	Series One	Series 90
CIMPLICITY 90-ADS	Genius	Modelmaster	Series Three	VuMaster
CIMPLICITYPowerTRAC	Genius PowerTRAC	ProLoop	Series Five	Workmaster

Preface

Content of this Manual

This book is a reference to the features, operation, installation, and configuration of the GE Fanuc Series 90™-30 I/O Link Master Module (IC693BEM321).

Chapter 1. Introduction: Describes the functions and features of the Series 90-30 I/O Link Master Module.

Chapter 2. Installation: Includes basic setup procedures for the I/O Link and for the I/O Link Master Module.

Chapter 3. Configuration: Describes configuration of an I/O Link Interface Module, using a Hand-held Programmer or the Logicmaster 90 Configuration software, release 4.5 or later.

Chapter 4. Operation: Describes how data is exchanged between the master and slaves on an I/O Link. Chapter 4 also explains how the PLC CPU interacts with the I/O Link Master Module and describes data formats.

Related Publications

Hand-held Programmer User's Manual (GFK-0402). This book describes the Hand-held Programmer displays, and explains operator procedures for module configuration, programming, and data monitoring.

Series 90-30 Installation and Operation Manual (GFK-0356): This manual is the primary reference for information about the Series 90-30 PLC.

We Welcome Your Comments and Suggestions

At GE Fanuc automation, we strive to produce quality technical documentation. After you have used this manual, please take a few moments to complete and return the Reader's Comment Card located on the next page.

Libby Allen
Senior Technical Writer

Contents

Chapter 1	Introduction	1-1
	System Overview	1-1
	Module Description	1-3
	Module Specifications	1-5
	Compatibility	1-5
	Getting Started	1-6
 Chapter 2	 Installation	 2-1
	Installing the I/O Link Master Module	2-2
	Removing the I/O Link Master Module	2-4
	Connecting the I/O Link Master Module to Other Devices	2-5
	Cable Types for the I/O Link	2-6
	Serial Port Pin Assignments	2-7
	Cable Diagram, No Optical Adapter	2-8
	Cable Lengths on the I/O Link	2-9
	Optical Adapter	2-10
	Optical Adapter Installation	2-11
	Cable Diagram, Electrical Cable to Optical Adapter	2-12
 Chapter 3	 Configuration	 3-1
	Overview of Configuration Steps	3-1
	Configuration Worksheet	3-2
	Entering Input Table References	3-3
	Entering Output Table References	3-3
	Configuring Slave Devices	3-4
	Configuring Input/Output Defaults	3-6
	Configuration Using the Hand-held Processor	3-7
	Entering the I/O Link Module's Input Table References	3-7
	Entering the I/O Link Module's Output Table References	3-7
	Configuring Slave Devices on the I/O Link	3-8
	Specifying the Slave Type	3-8
	Specifying the Slave's Input References	3-8
	Configuring Additional Slave Devices	3-9
	Setting Up Data Default or Hold Last State	3-9
	Configuration Using the LM90 Configurator	3-10
	Entering the I/O Link Module's Input Table References	3-11
	Entering the I/O Link Module's Output Table References	3-12
	Selecting Data Default or Hold Last State	3-12
	Configuring Slave Devices on the I/O Link	3-12
	Configuring Additional Slave Devices	3-13

Contents


Chapter 4	Operation	4-1
	Input and Output Data on an I/O Link	4-1
	I/O Link Operation	4-2
	Master Begins Sending Data	4-2
	Structure of Data Sent by the Master	4-3
	Slaves Return Data to Master	4-4
	Interruptions	4-5
	Data Defaults or Holds Last State	4-5
	Recovery	4-6
	Master CPU Operation	4-7
	Application Programming	4-7
	Data Formats in the Master CPU	4-8
	Input Data	4-8
	Output Data	4-11
	Content of this Manual	iii
	Related Publications	iii
	We Welcome Your Comments and Suggestions	iii

Chapter 1

Introduction

System Overview

The Series 90-30 I/O Link Master Module (IC693BEM321) allows a Series 90-30 PLC to act as a master on a proprietary Fanuc I/O Link. The Fanuc I/O Link is a serial interface which provides high-speed exchange of I/O data between the master and up to 16 slaves. The master can receive 1024 discrete inputs from slaves, and send up to 1024 discrete outputs.




The illustration above shows a simple I/O Link system: a Series 90-30 PLC used as a master, a Series 90-30 Hand-held Programmer, an I/O Link, and one slave.

In the illustration, the slave is a PowerMate CNC. Other devices that can be used as slaves include the Series 90-70 PLC, the Series 90-30 PLC, the Fanuc Series 0 CNC, Fanuc Connection Units, and Fanuc Operator Panels.

The module can be configured using the Logicmaster 90 (LM90) Configurator software, release 4.5, or a Series 90-30 Hand-held Programmer (HHP). The HHP can be used to monitor I/O states, and for the Model 331 Series 90-30 PLC, the HHP can also be used to override and force the states of I/O data exchanged with slaves.

Any number of I/O Link Master Modules can be installed in a Series 90-30 PLC. When there are multiple I/O Link Master Modules in the same PLC, they must be on separate I/O Links.

A more complex system is shown below. In this example, the master Series 90-30 PLC shown at the top functions as an area controller for a machine cell.




The devices in the machine cell that communicate with the master Series 90-30 PLC as slaves are: a Series 0 CNC, two single-axis Power Mate CNCs, and another Series 90-30 PLC. The slave Series 90-30 PLC is equipped with I/O Link Interface (slave) Module #IC693BEM320.

Module Description

The Series 90-30 I/O Link Master Module is a standard Series 90-30 PLC module. It plugs easily into the PLC's baseplate. The latch on the bottom of the module secures it in position. The module's front cover is removable.

An I/O Link Master Module occupies one module slot in a Series 90-30 PLC rack. It can be installed in any slot in any rack, except rack 0 slot 1, which is reserved for the CPU Module.


With a 30-watt Power Supply, the maximum number of I/O Link Master Modules that can be installed in the CPU rack is six, assuming that no other I/O modules are installed, and that the optical cable adapter for the I/O Link is not used. To determine the exact number of modules allowed in your system, use the +5V current specifications listed in the table on page 1-5 and in the *Load Requirements for Hardware Components* section in chapter 3 of the *Series 90-30 Installation and Operation Manual* (GFK-0356).



Fuse

The cutaway drawing on the right above shows the location of the fuse, directly below the Restart pushbutton.

This fuse protects the +5 volt signal pins used by the Optical Adapter cable. It is a replaceable 0.5A fast-blow fuse (5mm diameter x 20mm length).



LEDs

The module has three LEDs that show its operating and communications status.

ModuleOK	Module Configured	Link Active	Meaning
off	off	off	No power to module, or power up in progress
on	off	off	Module powered up but not configured
on	on	off	Module powered up and configured with minimum configuration (input status reference assigned and output status reference assigned), but link is not yet active, or has been activated but has gone down
on	on	on	Normal operation with active link

After power-up, the OK LED should remain ON. The CFG LED goes on after the CPU supplies the module configuration. The ACTV LED goes on when link communications have been established.

Restart Pushbutton

The LINK RESTART pushbutton provides a convenient means of restart if a failure occurs. Pushing the Restart pushbutton restarts the operation of the link.

Note

Pushing the LINK RESTART button while the link is operating has no effect. If the link stops operating, all slaves must be power-cycled before using the LINK RESTART pushbutton to restart operation of the link.

Serial Port

The front of the module has one 20-pin, Honda-type connector, used for connection to the first slave on the I/O Link. Signal levels are RS422 / 485 compatible.

Module Specifications

Module type:	Series 90-30 PLC module, providing I/O Link communications with I/O master.
I/O Points:	1024 inputs and 1024 outputs
+5V current:	without Optical Adapter connected: 415mA with Optical Adapter: 615mA
Environmental:	
Operating temperature	0C to +60C (32F to +140F)
Storage temperature	-40C to +85C (-40F to +185F)
Humidity	5% to 95% (non-condensing)
Vibration	3.5mm peak-to-peak displacement 5 to 150Hz
Shock	15G for 11mS duration
Altitude	Operating: 10,000 feet Non-operating: 40,000 feet

Compatibility

The Series 90-30 I/O Link Master Module is compatible with the following devices:

■ Host CPU

- Series 90-30 PLCs (models 311, 313, 321, 323, 331, and 341): release 4.4 or later.
- Series 90-30 Hand-held Programmer (HHP)

The module can be installed in any slot except the CPU slot, in any expansion rack, or in any remote rack in the Series 90-30 PLC. However, for best performance, it should be located in a CPU or expansion rack.

■ Programmer

- Hand-held Programmer
- Logicmaster™ 90-30 Programming Software Configurator, release 4.5 or later.
This module is not compatible with earlier versions of the Logicmaster software.

■ Slave Units

- Power Mate models A, C, D, and E
- Series 0 CNC
- Fanuc Operator Panel Unit
- Fanuc Connection Unit 1
- Fanuc Connection Unit 2
- Series 90-30 PLC with 90-30 I/O Link Slave Module
- Series 90-70 PLCs with 90-70 I/O Link Interface Module set up as slave

It is also possible to configure other types of devices as “universal” slaves, as explained in chapter 3.

Getting Started

To install and configure a Series 90-30 I/O Link Master Module, follow these basic steps:

1. Install the module and complete the I/O Link

Follow the instructions in chapter 2 to install the Series 90-30 I/O Link Master Module. After installing the other devices on the link (as instructed in their individual User's Manuals), complete the I/O Link cabling as instructed in chapter 2.

2. Configure the I/O Link Master Module

Follow the instructions in chapter 3 to configure the module using a Hand-held Programmer or the Logicmaster Configurator software (release 4.5 or later).

Chapter 2

Installation

This chapter tells how to install the I/O Link Master Module in the Series 90-30 PLC. It also explains how to connect the module to an I/O Link.

- Installing the I/O Link Master Module
- Removing the I/O Link Master Module
- Connecting the I/O Link Master Module to Other Devices
 - Cable types for the I/O Link
 - Serial Port Pin Assignments
 - Cable Diagram, No Optical Adapter
- Optical Adapter Installation
 - Cable Connections
 - Cable Diagram, Electrical Cable to Optical Adapter

Installing the I/O Link Master Module


The I/O Link Master Module can be installed in a Series 90-30 model 311, 313, 321, 323, 331, or 341 PLC (release 4.4 or later).

The module can be installed in any slot except the CPU slot, in any expansion rack, or in any remote rack in the Series 90-30 PLC. However, for best performance, it should be located in a CPU or expansion rack.

Caution

Rack power should be OFF when installing or removing the I/O Link Module.

1. Grasp the module with the front cover toward you and the rear hook facing away from you.
2. Align the module with its intended slot and connector. Tilt the module upward so that its top rear hook engages the slot on the baseplate.
3. Swing the module downward until the connectors mate and the locking lever on the bottom of the module snaps into place, engaging the baseplate notch.



4. Note the slot number; this will need to be entered when the module is configured. Configuration steps are described in chapter 3.

Caution

Make sure no exposed wiring touches any conductive material. Such contact could damage the module, and other units to which it is connected.

5. If CPU model 331 is to be used, make sure that the CPU is present before applying power to the I/O Link Master Module. Turn on power, and observe the LEDs.

ModuleOK	Module Configured	Link Active	Meaning
off	off	off	No power to module, or power up in progress
on	off	off	Module powered up but not configured
on	on	off	Module powered up and configured with minimum configuration (both input references and output references have been assigned), but link is not yet active, or has been activated but has gone down
on	on	on	Normal operation with active link

The OK LED should turn on. The other LEDs should remain off.

6. Configure the module using a Hand-held Programmer, as instructed in chapter 4. When the module has been configured, its Module Configured LED should go on.
7. Power cycle all the slaves and go to Run mode in the PLC (the link will not be established until the PLC is in Run mode). The I/O Link should now be operational, and the Link Active LED should go on.


Note

When an I/O Link Master Module is installed, the PLC issues an “Addition of Module” diagnostic.

Removing the I/O Link Master Module

1. Remove power from the PLC.
2. Remove the I/O Link connector from the front of the module.
3. Locate the release lever on the bottom of the module. Firmly press it up toward the module.
4. While holding the module firmly at the top, continue fully depressing the release lever and swing the module upward.
5. Disengage the hook at the top of the module by raising the module up and moving it away from the baseplate.

a43056



Note


When an I/O Link Master Module is removed, the PLC issues a “Loss of Module” diagnostic.

Connecting the I/O Link Master Module to Other Devices

The I/O Link cable connects the master, through each slave, to the last slave in the network in a "daisy chain" arrangement. The slaves are numbered according to their positions in the chain. Slave 0 is the slave closest to the master.

Using the correct cable type, connect the I/O Link Master Module to the first slave ("slave 0"). Connect any additional slaves (up to a total of 16 slaves) in the same manner. Be sure the order in which modules are connected to the I/O Link cable matches the order to be used during configuration.

Notice that the cables are marked JD1A on one end, and JD1B on the other.



Note

If the link also includes a Series 90-30 PLC used as a slave, attach the cable from the previous device to the top connector on the I/O Link Interface Module (IC693BEM320) as shown above.

Be sure the cable routing between modules on the I/O Link matches the configuration expected by the master. The excellent noise reduction of the cable used for the I/O Link allows it to be mixed with other signalling systems and 120 VAC control circuits, without needing added shielding or conduits. Conservative wiring practices, as well as national and local codes, require physical separation between control circuits and power distribution or motor power. Refer to sections 430 and 725 of the National Electric Code.

Cable Types for the I/O Link

The I/O Link consists of a full duplex serial data communications channel. Physically, the link consists of two twisted pairs of wire and a signal ground conductor. These wires are contained in a cable that has an over-all shield. Signals are of the differential type and a wire pair is used for each signal. Signal levels are compatible with specification EIA RS-422 / RS-485. The signal baud rate is 1.5 Mbaud maximum.

The following cables and connectors can be used to complete the I/O Link between devices.

Item	Catalog Number	Vendor	Description
Cable	A03B-0807-K801	GE Fanuc	5 meter length with connectors on both ends. Connects between master and slave device, or between two slave devices.
Cable	A03B-0807-K802	GE Fanuc	10 meter length with connectors on both ends. Connects between master and slave device, or between two slave devices.
Cable	AMW2076	OKIElectric Cable	10-pair shielded cable without connectors, for making custom-length cable. Connects between master and slave device, or between two slave devices.
Connector	A02B-0120-K301	GE Fanuc	20-pin connector with solder lug. Consists of the two following parts.
Connector	PCR-E20FS	Honda	20-pin female connector with solder lug.
	PRC-V20L	Honda	Connector cover.
Cable	A03B-0807-K803	GE Fanuc	1 meter length with connectors on both ends. Connects between master or slave and Optical Adapter. This cable can only be used with an Optical Adapter; do not use it for master / slave or slave / slave connections.
Optical Adapter	A138-154-B001	GE Fanuc	Required for optical fiber cable.
Cable	A66L-6001-009	GE Fanuc	Optical fiber cable for use with Optical Adapter.
	" #L10R03		10m
	" #L15R03		15m
	" #L20R03		20m
	" #L30R03		30m
	" #L40R03		40m
	" #L50R03		50m
	" #L60R03		60m
	" #L80R03		80m
	" #L90R03		90m
	" #L100R03		100m

Serial Port Pin Assignments

Pin #	Signal	Pin #	Signal
1	SIN	11	0 volts
2	*SIN	12	0 volts
3	SOUT	13	0 volts
4	*SOUT	14	0 volts
5		15	0 volts
6		16	0 volts
7		17	
8		18	+5 volts
9	+5 volts	19	
10		20	+5 volts

The +5-volt output powers the fiber optic link modules for long distance applications.


Caution

In all other cables, the signal pins for +5 volts should NOT be connected. These pins are protected by a replaceable 0.5A fast-blow fuse (5mm diameter x 20mm length) located inside the front of the module.

Cable Diagram, No Optical Adapter

The following illustration shows connection details for electrical cable used between a master and slave or between two slave devices. This cable (A03B-0807-K801, A03B-0807-K802, or cable made using AMW 2076 and connectors A02B-0120-K301) does not include the +5-volt signal. Do **not** use Optical Adapter cable, which includes the +5 volt signal, to directly connect master and slave devices.

a45019



Connect the differential signals, SIN / *SIN, and SOUT / *SOUT using twisted pair wires.

Caution


The I/O Link cable's shield must be connected to chassis ground in your system. Use the grounding cable (44A729227) provided.

Cable Lengths on the I/O Link

The maximum distance between the master and the first slave, and between successive slaves, depends on whether electrical or optical cable is used.

- The maximum length of an electrical cable link is 10 meters (33 feet).
- The maximum length of an optical fiber cable is 100 meters (330 feet).


Electrical and optical cables can be used in the same I/O Link.



a45006

Optical Adapter

An Optical Adapter (A138-154-B001) can be used to interface the electrical cable of the I/O Link with optical cable.



Use pairs of adapters in applications where:

- distances of up to 100 meters (330 feet) are required between any two devices on the I/O Link.
- the I/O Link runs between different cabinets, and it is not possible to connect the cabinets with a wire of 5.5mm^2 or thicker.
- excessive electromagnetic noise could affect the cable. This includes noise from machinery such as a welding machine, and noise-generating cable such as power cable that run for long distances with the I/O Link cable.


Optical Adapter Installation

An Optical Adapter must be installed in a sealed enclosure. Avoid contact with other electrical components or wiring, which could short the unit.

Use the adapter's casing screws to make earth ground connection. The electrical potential of the earth ground used for the adapter must be the same as that of the I/O Link to which it is connected.

Cable Connections


Connection between two Optical Adapters is made using optical fiber cable A66L-6001-009. Lengths of 10 to 100 meters are available. Connect the optical fiber cable to COP1 on the adapter unit.



Connection between a master or slave device and an Optical Adapter is made using electrical cable A03B-0807-K803, which is a one-meter cable with connectors on both ends. Connect this cable to JD1 on the adapter. A connection diagram is shown on the next page.

Cable Diagram, Electrical Cable to Optical Adapter

Cable A03B-0807-K803 provides the +5-volt signal required by the Optical Adapter. **Do not use this cable to directly connect master or slave devices; use it only with an Optical Adapter.**



The +5 volt output on the I/O Link Master module is protected by a replaceable 0.5A fast-blow fuse (5mm diameter x 20mm length).

Chapter 3

Configuration

There are two methods for configuring the I/O Link Master module:

- on-line configuration using the Hand-held Programmer.
- off-Line configuration using the Logicmaster 90 Configurator software (release 4.5 or later required) and then downloading the new configuration to the PLC when on-line.

The following Overview applies to both methods of configuration and should be read before configuring the module. A worksheet is provided on page 3-2 for your use in planning module configuration.

Overview of Configuration Steps

The I/O Link Master module must be installed in its selected slot in a Series 90-30 PLC baseplate and powered up. The HHP presents the configuration parameters in the order shown in the steps below. If you are using the Logicmaster 90 software, the I/O defaults (steps D and E below) are configured before the slave devices (step C). Using either configuration method, you can return to a previously configured parameter and edit it.

- A. Enter input table (%I) references for the module's status information (information provided by the module to the PLC). See the explanation on page 3-3.
- B. Enter output (%Q, %AQ, %G, or %R) references for the module's "command word" (information sent from the PLC to the module). Specify 16 %Q bits, 1 %AQ word, 16 %G bits, or 1 %R word. See page 3-3.
- C. Specify the following for each slave position on the link (see page 3-4):
 1. the device type.
 2. input table (%I) references and length for that slave. Note that the output table (%Q) references and length for each slave are computed automaticallyEnter the information for all planned slaves before going on to the next step.
- D. Specify whether the module should default input data to 0 or hold data at its last state if the link fails (see page 3-6).
- E. Specify whether the module should default output data to 0 or hold data at its last state if the link fails (see page 3-6).

Configuration Worksheet

Master:

Input Status references (24 bits): ☐%I _____ to ☐%I _____

Output references (16 bits): ☐%Q or ☐%AQ
☐%G or ☐%R _____ to _____

Slaves:

0: Device type: _____
☐%I or ☐%AI _____ to _____

1: Device type: _____
☐%I or ☐%AI _____ to _____

2: Device type: _____
☐%I or ☐%AI _____ to _____

3: Device type: _____
☐%I or ☐%AI _____ to _____

4: Device type: _____
☐%I or ☐%AI _____ to _____

5: Device type: _____
☐%I or ☐%AI _____ to _____

6: Device type: _____
☐%I or ☐%AI _____ to _____

7: Device type: _____
☐%I or ☐%AI _____ to _____

8: Device type: _____
☐%I or ☐%AI _____ to _____

9: Device type: _____
☐%I or ☐%AI _____ to _____

10: Device type: _____
☐%I or ☐%AI _____ to _____

11: Device type: _____
☐%I or ☐%AI _____ to _____

12: Device type: _____
☐%I or ☐%AI _____ to _____

13: Device type: _____
☐%I or ☐%AI _____ to _____

14: Device type: _____
☐%I or ☐%AI _____ to _____

15: Device type: _____
☐%I or ☐%AI _____ to _____

Data Defaults:

Inputs: ☐ default to 0 or ☐ hold last state

Outputs: ☐ default to 0 or ☐ hold last state

Entering Input Table References

The I/O Link Master Module requires 24 bits of %I memory in the Series 90-30 PLC. The module uses these bits to provide status information to the PLC.


The maximum number of inputs allowed is 1024 bits (128 bytes or 64 words), not including the 24 bits used for status information. If this limit is exceeded, an error message is generated.

Note

Each slave on the I/O Link also requires input memory. When you configure the slaves (in a later step), you can assign each to any available references in %I or %AI memory.

Input Data References for an I/O Link

The locations assigned to the I/O Link Master module and the slaves on the I/O Link may or may not be grouped together in memory, as illustrated below.



Entering Output Table References

The I/O Link Master Module requires 16 bits of %Q or %AQ memory in the Series 90-30 PLC. During system operation, the PLC uses these bits to provide command information to the module.

The maximum number of outputs allowed is 1024 bits (128 bytes or 64 words), not including the 16 bits used for command information. If this limit is exceeded, an error message is generated.


Note

The location of the command information for the module also determines the location of all data transmitted from the Series 90-30 PLC to the slaves on the I/O Link.

Output Data References for an I/O Link

The command data for the I/O Link Master module and output data for slave devices on the I/O Link reside together in memory. Output data for the slaves immediately follows the 16 bits of command data in the selected memory area (%Q, %AQ, %G, %R).

%Q, %AQ, %G, or %R Memory



Configuring Slave Devices

Slave devices 0–15 are configured in sequence, beginning with the slave that is the next device on the link (Slave 0). For each slave, the default slave type is **NONE**.

The total number of I/O points allowed on the I/O link bus consists of 1024 inputs and 1024 outputs. The table on page 3-5 shows the number of inputs and outputs used by each slave type in the 90-30 PLC. However, the number of points used by a slave device on the link is always a power of 2 (16, 32, 64, 128, 512). If a device in the table shows 96 inputs (Customer Operations Panel A or Connection Unit 1), it actually uses 128 of the allowed 1024 input points on the link, while only using 96 inputs in the 90-30 PLC. In the case of Connection Unit 01 & 02 which shows 192 inputs, the device uses 256 of the allowed 1024 input points on the I/O Link, while using only 192 input points in the 90-30 PLC.

Use the “universal” slave selections (slave256, slave128, slave64, and slave 32) only if you need to configure a type of device that is not specifically listed in the table on page 3-5 or recognized by the programming software. Because these selections do not represent specific device types, the I/O Link Master module is not able to verify that a correct slave module type is actually present at that location, but facilitates the I/O exchange.

After selecting each slave type, assign its starting input (%I or %AI) reference and length. Unlike outputs, which use a block of references, the input references for slaves do not

need to be in sequential order. It is possible to assign some slaves to %I memory, which is bit-mapped, and other slaves to %AI memory which is word-based. (See the explanation on page 3-3).

It is possible to assign input references that overlap, but the configuration will be invalid and will not be stored.


Output references (%Q, %AQ, %G, or %R) are automatically assigned in sequential order for each configured slave. If, after configuring the slaves, you edit the reference address for the module command information, the slave output references will be automatically reconfigured.

Configuration Information for Slave Devices

Slave Type	HHP Abbreviation	LM90 Abbreviation	Description and I/O Points
none	None	NONE	there is no slave assigned to the selected position
PowerMate64	PwrMate64	PWMATE64	PowerMate CNC using 64I / O points
PowerMate32	PwrMate32	PWMATE32	PowerMate CNC using 32I / O points
90-30 slave 64	30slave64	30SLAV64	Series 90-30 PLC with I / O Link Interface(slave) module, using 64I / O points
90-30 slave 32	30slave32	30SLAV32	Series 90-30 PLC with I / O Link Interface(slave) module, using 32I / O points
Series0C64	S0C64	SOC 64	Series 0C CNC using 64I / O points
Series0C32	S0C32	SOC 32	Series 0C CNC using 32I / O points
Customer Operators Panel A	Cust Op A	CUSTOP A	Customer Operators Panel using 96 input and 64 output points
Customer Operators Panel B	Cust Op B	CUSTOP B	Customer Operators Panel using 64 input and 32 output points
Connection Unit 01	CN 01	CN 01	Connection Unit 01 using 96 input and 64 output points
Connection Unit 01 & 02	CN 02	CN 02	Connection Units 01 and 02 using 192 input and 128 output points
90-70 slave 64	70slave64	70SLAV64	Series 90-70 PLC with I / O Link Interface Module set up as a slave, and using 64I / O points
90-70 slave 32	70slave32	70SLAV32	Series 90-70 PLC with I / O Link Interface Module set up as a slave, and using 32I / O points
Universal256	Slave256	SLAVE256	Any slave using 256I / O points
Universal128	Slave128	SLAVE128	Any slave using 128I / O points
Universal64	Slave64	SLAVE64	Any slave using 64I / O points
Universal32	Slave32	SLAVE32	Any slave using 32I / O points

Configuring Input/Output Defaults

This configuration step specifies how the module will operate if it stops receiving data from slaves on the link, or from the PLC (for example, if the PLC is in STOP mode).



If normal operation stops, the module can either default input or output data to 0 (OFF), or continue transmitting the last valid data it received (HOLD LAST).

Note

Procedures for configuration using the Hand-held Processor begin on page 3-7. To configure the module using the LM90 Configurator software, go to page 3-10.

Configuration Using the Hand-held Processor

1. With the module's rack and slot location displayed by the HHP, press the **HHP READ** and **ENTER**  keys. The HHP displays:

R0:01 FM3 x.yz
I24:___

FM3 is the abbreviation for the I/O Link Master Module. The digits "x.yz" show the module's firmware version.

2. With the HHP, configure the following, using the  key to go through the selections, and the **ENTER**  key to actually make each selection. If you want to go back to an earlier selection, use the  key.

Entering the I/O Link Module's Input Table References

The I/O Link Master Module requires 24 bits of %I memory in the Series 90-30 PLC. The module uses these bits to provide status information to the PLC.

The maximum number of inputs allowed is 1024 bits (128 bytes or 64 words), not including the 24 bits used for status information. If this limit is exceeded, the HHP responds with a configuration error (**CFGerr**).

When you configure the I/O Link Master module with the HHP, the next available starting reference in %I memory automatically appears for the status bits. You can use this reference, or enter a different reference.

If you want to specify a different reference, enter the number using the HHP keypad. Press the **ENTER**  key to accept your entry.

Entering the I/O Link Module's Output Table References

The I/O Link Master Module requires 16 bits of %Q, %AQ, %G, or %R memory in the Series 90-30 PLC. During system operation, the PLC uses these bits to provide command information to the module.

The maximum number of outputs allowed is 1024 bits (128 bytes or 64 words), not including the 16 bits used for command information. If this limit is exceeded, the HHP responds with a configuration error (**CFGerr**).

If no slaves have been configured, output memory can be configured using the following keystrokes on the HHP:

Memory type: HHP keystrokes

%Q	Q ENTER  1 6 ENTER  (desired starting address)* ENTER 
%AQ	Q Q ENTER  1 ENTER  (desired starting address)* ENTER 
%G	G ENTER  1 6 ENTER  (desired starting address)* ENTER 
%R	R ENTER  1 ENTER  (desired starting address)* ENTER 

*If a starting address is not specified, the next available address is assigned.

If slaves have been configured and you wish to change the output memory type or starting address, the key sequence is the same, except that for %Q and %G memory, the output length is 16 plus the number of input points configured for the slaves.

Configuring Slave Devices on the I/O Link

Configure the slaves in sequence, beginning with the slave that is the device on the link closest to the module. Configure that device as 0. For each slave from #0 to #15, the HHP originally displays “none”.

```

      R0:01 FM3    <S
      #O :NONE
slave  _____ type
number

```

Specifying the Slave Type

For each slave position, use the HHP's +/- key to display the abbreviations of potential devices, as listed in the table on page 3-5.

When the correct choice for that link location appears, press the **ENTER**  key to accept it. The I/O Link Master module checks the slave device in that location to be sure it is the correct type.

Specifying the Slave's Input References

1. Specify the memory type. If you want to change the displayed memory type, use the HHP's **I/AI** key. To select %I memory, press the key once. To select %AI memory, press it twice. Press the **ENTER**  to accept it. The first choice that appears is “Ignore Device”.

```

      R0:01 FM3 #0 <S
      Ignore Device

```

2. Enter the correct data length for the type of slave you are configuring. If the selected memory type is %I, enter a length in bits. If the selected memory type is %AI, enter a length in words (16 bits each).

Be sure the length you enter is correct for the type of slave being configured. If you enter an incorrect length, the Hand-held Programmer will not permit you to proceed to the next slave. If that happens, correct the length entry. Press the **ENTER**  key to accept it. If you selected %I memory and then entered a length of 64, the screen would display:

```

      R0:01 FM3 #0 <S
      I0064:I_

```

3. Specify a starting reference. If you are satisfied with the complete selection for the slave device, press the **ENTER**  to accept it. If you want to change it, do not press **ENTER** . Instead, press the **CLR** key then make a different entry. For the above example, the display would be:

```

      R0:01 FM3 #0 <S
      I0064:I0025-0088

```

Configuring Additional Slave Devices

To configure the next slave, press the HHP's ➡ key. (If you cannot go to the next slave, it is because you have entered an incorrect length for that slave type).

Configure all the slaves on the link without skipping slave numbers. After you configure the last slave, press the HHP's ➡ key to go to the next configuration step.

Setting Up Data Default or Hold Last State

Input (%I or %AI) Data Defaults or Hold Last State

First, specify how the I/O Link Master Module should operate if it stops receiving data from slaves on the I/O Link. It can either continue providing the CPU with the last valid input states it received from the slaves or default all inputs to 0.

Select either **DEFAULT** or **HOLD**. Press the **ENTER** ↵ key to accept the selection.

R0:01 FM3 <S
Input : HOLD

Output (%Q or %AQ) Data Defaults or Hold Last State

Finally, specify how the module should operate if it stops receiving output data from the PLC CPU. It can either continue retransmitting the last set of data it received from the PLC CPU or default all outputs to 0.

Select either **DEFAULT** or **HOLD**. Press the **ENTER** ↵ key to accept the selection.

R0:01 FM3 <S
Output : HOLD

Configuration Using the LM90 Configurator

With the I/O Link Master Module installed in its proper rack / slot location, the LM90 configurator software program (release 4.5 or later) can be used to configure the module in the off-line mode. Once the complete set of configuration data has been entered, it must then be downloaded to the PLC (in the on-line mode) to become effective in the I/O Link Master Module.

The I/O Link Master Module is configured by completing setup screens in the Logicmaster 90-30 configuration software. The setup screens that are used for this module are shown and described below.

In the I/O configuration screen, place the cursor at the slot representation corresponding to the module's installed location in the PLC rack.

RACK 1 2 3 4 5 6 7 8 9 10

1 30 io 2 genius 3 4 ps 5 racksel 6 conn 7 8 other 9 10 zoom

>

PS	1	2	3	4	5	6	7	8	9	10													
=====	P	R	O	G	R	A	M	E	D	C	O	N	F	I	G	U	R	A	T	I	O	N	=====
PWR321	CPU331																						

OFFLINE

C:\LM90\SYSTEM3 PRG: SYSTEM3 CONFIG VALID

REPLACE

Select F8 (**other**). The following screen will appear.

RACK 1 2 3 4 5 6 7 8 9 10

1 pcn 2 hsc 3 fgrn 4 oi 5 apn 6 iolink 7 iop 8 9 10

>

SERIES 90-30 MODULE IN RACK 3 SLOT 3

SOFTWARE CONFIGURATION

SLOT 3 Catalog #: _____

OFFLINE

C:\LM90\SYSTEM3 PRG: SYSTEM3 CONFIG VALID

REPLACE

Press F6 (**iolink**). The following catalog screen will appear.

```

RACK 1pcn 2hsc 3frgn 4oi 5apn 6iolink 7iop 8 9 10
>
SERIES 90-30 MODULE IN RACK 3 SLOT 3
SOFTWARE CONFIGURATION
SLOT 3 Catalog #:
  CATALOG #  DESCRIPTION  TYPE
  1  IC693BEM321  9030 I/O LINK MASTER  IOLINK

  << CURSOR TO THE DESIRED CATALOG NUMBER AND PRESS THE ENTER KEY >>
  << PRESS PGDM KEY FOR NEXT PAGE, PGUP KEY FOR PREVIOUS PAGE >>

OFFLINE
C:\LM90\SYSTEM3  PRG: SYSTEM3  CONFIG VALID
REPLACE
  
```

With the 90-30 I/O Link Master selected, press the ENTER key. The following detail screen for the 90-30 I/O Link Master module will appear.

```

RACK 1pcn 2hsc 3frgn 4oi 5apn 6iolink 7iop 8 9 10
>
SERIES 90-30 MODULE IN RACK 3 SLOT 3
SOFTWARE CONFIGURATION
SLOT 3 Catalog #: IC693BEM321 9030 I/O LINK MASTER
BEM321
IOLINK
      %I,%Q,%G lengths are bits; %AI,%AQ,%R are words
Status Ref : %I0001  Command Ref: %Q0001  Input Def : OFF
Status Len : 24      Command Len: 16      Output Def : OFF

----- SLAVE #0 -----
Slave Type : NONE

----- SLAVE #1 -----
Slave Type : NONE

<< More Config Data Exists: PgDn for Next Page, PgUp for Previous Page >>

OFFLINE
C:\LM90\SYSTEM3  PRG: SYSTEM3  CONFIG VALID
REPLACE
  
```

From here, you can configure the I/O Link Master Module as desired. For this module, there are six pages of configuration parameters. Use the **PGUP** and **PGDN** keys to move from one page to another. Use the directional keys to move the cursor to each configurable parameter. Pressing the **Tab** key causes the display to toggle through the available values for a selected parameter. (Pressing the Shift and Tab keys together causes the display toggle through the values in reverse order.)

Entering the I/O Link Module's Input Table References

- Status Ref** Reference address for the module's diagnostic data (%I). *Default: next available reference for the reference type*
- Status Len** Length of Status Ref. The value of this parameter is fixed at 3 bytes (24 bits). *Can not be edited.*

Entering the I/O Link Module's Output Table References

Command Ref Reference address for the module's command word. %Q is the default memory type. Other memory types can be selected by entering **AQ**, **G**, or **R** and pressing the **ENTER** ↵ key. Press the **Tab** key to change the starting address. Press the **ENTER** ↵ key to accept the starting address.

Command Len Length of Command Ref. The value of this parameter is fixed at 2 bytes (16 bits). *Can not be edited.*

Selecting Data Default or Hold Last State

Input Def The state presented to the PLC for all %I references of the module if communication is lost. **HOLD** causes the last state to be input. **OFF** causes the input to be set to 0. *Default: OFF*

Output Def The state presented to the PLC for all %Q and %AQ references of the module if communication is lost. **HOLD** causes the last state to be output. **OFF** causes the output to be set to 0. *Default: OFF*

Configuring Slave Devices on the I/O Link

Configure the slaves in sequence. For each slave, the default **Slave Type** is **NONE**. When one of the other types is entered, the **Input Ref**, **Input Len**, **Output Ref**, and **Output Len** parameters are displayed.

Slave Type The available slave types and their input / output lengths are listed in the table on page 3-5. Press the **Tab** key to toggle through the choices. When the correct choice for that link location appears, press the **ENTER** ↵ key to accept it. The I/O Link Master module checks the slave device in that location to be sure it is the correct type. *Default: NONE*

Input Ref Input reference address for the configured slave type. %I is the default memory type. Select %AI by entering AI and pressing the **ENTER** ↵ key. Press the **Tab** key to change the starting address. Press the **ENTER** ↵ key to accept the starting address. *Default: next available reference offset for the reference type*

Note

The following parameters are automatically supplied by the software and can not be edited.

Input Len Length of Input Ref. The value of this parameter is automatically supplied based on the Slave Type (see page 3-5).

Output Ref Output reference address for the configured Slave Type. The value of this parameter is automatically supplied based on the Command Ref type and the Slave Type.

Output Len Length of Output Ref parameter. The value of this parameter is automatically supplied based on the Slave Type.

The following screen shows a typical configuration for slaves 0 and 1. Slaves 2–15 can be configured in a similar manner.

RACK	1pcn	2isc	3frgn	4oi	5apn	6iolink	7iop	8	9	10
>										
SERIES 90-30 MODULE IN RACK 3 SLOT 3										
SOFTWARE CONFIGURATION										
SLOT 3	Catalog #: IC693BEM321 9030 I/O LINK MASTER									
BEM321	%I,%Q,%G lengths are bits; %AI,%AQ,%R are words									
IOLINK	Status Ref : %I0001 Command Ref: %Q0001 Input Def : OFF Status Len : 24 Command Len: 16 Output Def : OFF									
----- SLAVE #0 -----										
Slave Type : 70SLAU32 Input Ref : %I0025 Output Ref : %Q0017 Input Len : 32 Output Len : 32										
----- SLAVE #1 -----										
Slave Type : SLAVE256 Input Ref : %I0057 Output Ref : %Q0049 Input Len : 256 Output Len : 256										
<< More Config Data Exists; PgDn for Next Page, PgUp for Previous Page >>										
OFFLINE										
C:\LM90\SYSTEM3					PRG: SYSTEM3			CONFIG VALID		
REPLACE										

Configuring Additional Slave Devices

Press the **PGDN** key to proceed to the remaining screens. Configure the remaining slave devices in sequence. The software does not allow you to skip a slave (i.e., configure a slave if the slave type of the previous device is NONE).

When the module, including slaves, has been configured to your satisfaction, press the **ESC** key. The following screen will appear.

RACK	COPY	REF UU	DELETE	UNDEL	6comm	7	8other	9	10zoom
1n30 io	2genius 3	4ps	5rcksel	6comm	7	8other	9	10zoom	
>									
===== RACK 3 =====									
PS	1	2	3	4	5	6	7	8	9
===== P R O G R A M M E D C O N F I G U R A T I O N =====									
PWR321	CPU331		BEM321						
			IOLINK						
OFFLINE									
C:\LM90\SYSTEM3					PRG: SYSTEM3			CONFIG VALID	
REPLACE									

Chapter 4

Operation

This chapter describes operation of the I/O Link, I/O Link Interface Module, and PLC CPU.

- I/O Link Operation
 - Master Begins Sending Data
 - Structure of Data Sent by the Master
 - Slaves Return Data to Master
 - Interruptions
 - Data Defaults or Holds Last State
 - Recovery
- Master CPU Operation
 - Application Programming
 - Data Formats in the Master CPU
 - Input Data
 - Status Input Bits
 - Output Data


Input and Output Data on an I/O Link

For each device on an I/O Link:

- **Input Data** is data received from the link.
- **Output Data** is data sent to the link.

So the *same* set of data is considered output data by the device that sends it and input data by the device that receives it.

a45008




I/O Link Operation

Normal operation begins when:


- the I/O Link Master module has been configured.
- the Series 90-30 PLC has been placed in Run mode.

Master Begins Sending Data

The PLC CPU sends data from the configured %Q and / or %AQ references to the I/O Link Master module.



After receiving this output data from the PLC CPU, the I/O Link Master module begins transmitting it to slave devices on the I/O Link.




The I/O Link Master module does *not* begin transmitting until it has received valid output data from the PLC CPU.

Note that the I/O Link Master module's Link ACTV LED and the equivalent %I status bit are not turned on until the module receives data back from the slave devices.

Structure of Data Sent by the Master

The I/O Link Master module sends output data for all slave devices in a continuous serial string. Slaves receive the data in order of their positions on the link. Each slave in turn reads out its configured amount of data, and passes the remainder on to the next slave. To a slave, data received from the master is input data.


a45009



Multiple slaves on a link are connected in a daisy-chain fashion so that the output of the first slave drives the input to the second, and so on. With this cabling sequence, each input appears as a single load to the slave that is driving it; therefore, loading on a particular slave output does not change with the total number of slaves in a system.


Slaves Return Data to Master

At initialization, slave devices start sending data.



When the I/O Link Master module receives data from slave 0, its Link ACTV LED lights, and it sets the equivalent %I status bit to 1.

The I/O Link Master module then provides this data to the PLC CPU, where it is placed in the slave devices' assigned %I and / or %AI input references:



Interruptions


Normal operation can be disrupted by:

- placing the master Series 90-30 PLC into STOP mode.
- losing power at one of the slaves.
- losing transmissions from one of the slaves.
- a cable break.

Data Defaults or Holds Last State


Whenever the PLC CPU is placed in STOP mode or is stopped for any other reason, it no longer provides fresh output data to the I/O Link Master module to send to slaves on the I/O Link. When this happens, the I/O Link Interface module internally defaults all output data to 0 or holds all data in its last valid state. This choice depends on the module's configuration, and is the same for all slaves on the I/O Link.

As long as the I/O Link Master module itself is operating, it continues to send this data to the slaves.



Similarly, if a slave loses power or stops transmitting data on the I/O Link, or if the link cable breaks, the I/O Link Master module no longer receives fresh input data to provide to the PLC CPU. When this happens, the I/O Link Interface module internally defaults that input data to 0 or holds all data in its last valid state. This choice depends on the module's configuration, and is the same for all slaves on the I/O Link.

The module continues to supply this data to the PLC CPU.



Recovery

Follow this procedure to restore normal operation.

1. Correct the condition that caused the interruption.
2. Cycle power to each slave (turn power off, then on again).
3. **After the problem has been completely corrected**, restart the link by *either*:
 - A. pressing the Restart switch on the module faceplate, or
 - B. activating the Restart command bit in the Command Word as a one-shot. (See page 4-12 for more information).


Caution

If the I/O Link is restarted before all problems with the I/O Link cables or the slaves have been completely corrected, the I/O Link Master module may establish a link with less than the intended number of slaves.

Master CPU Operation

The PLC CPU handles I/O Link data in the same manner as other types of I/O data. The CPU reads inputs from the I/O Link's assigned %I and %AI references, then executes its application logic, then writes outputs to the appropriate %Q/%AQ references.

This is shown in simplified fashion by the following illustration.



Application Programming

The application program running in the Series 90-30 PLC CPU performs some or all of the following actions:

- it reads the most recent input data it has received from slaves on the I/O Link from %I and / or %AI memory.

Input and output data formats are explained in more detail on the following pages.

- at startup (or when restarting the system), the application program should:
 - monitor the least significant 8 bits (byte 1) of the status bits to inform the PLC CPU about the overall health of the I/O Link.
 - monitor status bit 4 to be sure all of the configured slave devices are actually present. If bit 4 = 1, the application program may shut down operation of the system as a safety precaution.
 - monitor the rest of the status bits to be sure the correct slave is present at each configured location.
- it supplies data to slaves by placing the data into the slaves' assigned output references.
- if the PLC CPU and the I/O Link Master are operating, but the I/O Link has failed, the application program can use output bit 0 to restart the link.

Data Formats in the Master CPU


As explained previously, the I/O Link Master module and the slaves on the I/O Link use both input and output references in the Series 90-30 PLC.

Data exchanged between the I/O Link Master module and the slaves on the I/O Link is coherent across 16 bits. Every 16-bit word, beginning with the starting reference assigned to each slave, is from the same data transmission. It is possible to have successive words of data to or from the same slaves that are from successive “scans” of the I/O Link.

Input Data

The I/O Link Master module itself requires 24 bits of %I memory in the Series 90-30 PLC. In addition, slaves on the I/O Link can be independently assigned to %I and / or %AI memory during configuration. The appropriate memory type (%I for bit data or %AI for word data) and length are configured for each slave.

The locations assigned to the I/O Link Master module and the slaves on the I/O Link may or may not be grouped together in memory, as illustrated below.




Input Status Bits

The I/O Link Master module reserves 24 bits of %I memory to inform the PLC CPU of its status, and that of the I/O Link. The application program can monitor these bits, and take appropriate action if necessary.

The I/O Link Master module uses the least significant 8 bits (byte 1) of the status bits to inform the PLC CPU about the overall health of the I/O Link.

Bits 8 through 23 inform the PLC CPU if it encounters a configuration mismatch at any slave location(s) when either initializing or restarting the I/O Link.



See the descriptions of these bits on the next page.

Status Bit 7: Link Status

Input status bit 7 corresponds to the module's ACTV LED. If the link is active, the I/O Link Master module sets bit 7 to 1. If the link fails, the I/O Link Master module clears bit 7 to 0.

Status Bits 0 to 4: Absent Slaves

During link initialization, if the I/O Link Master determines that one or more of the configured slave devices is missing, it sets bit 4 to 1. The link may still operate, but some slaves will not be present. The application program can monitor bit 4, and take appropriate action if any slaves are absent.

If bit 4 is 1, program logic can identify the lowest missing slave by checking bits 0 - 3. The I/O Link Master module cannot distinguish between a slave lost due to a power failure and a slave lost due to a cable break. If, before the I/O Link Master established the I/O link, power failed at slave #5 or a cable break existed between slave #4 and slave #5, the I/O Link Master status would indicate that slave #5 was missing. Slaves 0 through 4 would be on line.

Status Bits 8 to 23: Slave Configuration Mismatch

The I/O Link Master uses the rest of the status bits to inform the PLC CPU if it encounters a configuration mismatch at any slave location(s) when either initializing or restarting the I/O Link. Either the configuration must be corrected, or the physical setup of the slaves must be changed (for example, if modules have been connected, or reconnected, to the link cable in the wrong sequence).


Note

The link may continue to operate if a mismatch is present.

Output Data

The I/O Link Master module itself requires 16 bits of %Q or %AQ memory in the Series 90-30 PLC. In addition, slaves on the I/O Link are automatically assigned to the same type of memory directly following that used by the I/O Link Master.

The locations assigned to the I/O Link Master module and the slaves on the I/O Link are always grouped together in memory, as illustrated below.



The application program supplies data to slaves on the I/O Link by placing it into the slaves' assigned output references.

During configuration, the memory type and starting address for I/O Link output data can be selected. As slaves are configured on the link, their output addresses and lengths are assigned automatically. Two examples are discussed below.

Example 1: Suppose the beginning address configured for I/O Link output data is: **%Q401**

The first 16 references from **%Q401** through **%Q416** are used for command bits.

The first slave (slave #0) is a Power Mate set up as a 64-bit slave (PwrMate64). Its output data will be located directly after the command bits, at:

%Q417 through %Q480

The next slave (slave #1) would then be assigned references beginning at **%Q481**.

Example 2: If the beginning address configured for I/O Link output data is:

%AQ006

The first word (**%AQ006**) is used for command bits.

The first slave (slave #0) is a Power Mate set up as a 64-bit slave (PwrMate64). Its output data will be located directly after the command word, at:


%AQ007 through %AQ010

The next slave (slave #1) would then be assigned references beginning at **%AQ011**.

Output Command Bits

The I/O Link Master module reserves 16 bits of %Q memory for commands from the application program.

At present, only two of these bits are used.



These two commands operate as one-shots, so they cannot interfere with each other. The I/O Link Master module executes the Restart command only then the I/O Link is not operating. It executes the Reset command only when the link is operating.

Output Command Bit 0: Restart Non-operational I/O Link

Bit 0 (the least significant bit) can be used in the same way as the module's Restart pushbutton. If the PLC CPU and the I/O Link Master are operating, but the I/O Link has failed, the application program can use this bit to restart the link. Note that this bit is ignored if the link is already active.

It is important to use this bit properly. Normally, it should be set to 0. To use it, it should be turned on for exactly one CPU scan *after the I/O Link problem has been corrected, and all the slaves power-cycled*.

Caution

If this bit is allowed to remain on, the I/O Link Master might establish a link with less than the intended number of slaves. As soon as slave #0 is power-cycled, the I/O Link Master sets up a link consisting of those slaves that have been power-cycled, up to the first slave not ready to communicate.

Output Command Bit 1: Reset Operating I/O Link

Bit 1 can be used to reset the I/O Link if it is presently operating. When the I/O Link Master module receives this command from the application program it stops sending outputs to the slaves, and turns off both its ACTV LED and its Link Active status bit (input status bit 7, see pages 4-9 and 4-10).

This bit should normally be set to 0. It should be turned on for exactly one CPU scan to reset the I/O Link. Note that this bit is ignored if the link is already inactive.

A

Addition of Module diagnostic, 2-3

Application program, 4-7

C

Cable

- break, 4-5

- connections, 2-5

- diagrams, 2-8 , 2-12

- lengths, 2-9

- twisted pair, 2-8

- types and connectors, 2-6

Catalog numbers

- cables and connectors, 2-6

- Grounding Cable, 2-8

- I/O Link Interface (slave) module, 1-2

- I/O Link Master module, 1-1

Chassis ground, 2-8

Command information, 3-3

Compatibility, 1-5

Configuration

- input / output defaults, 3-6

- overview, 3-1–3-6

- slave devices, 3-4 , 3-5 , 3-8 , 3-12

- using Hand-held Processor, 3-7–3-9

- using LM90 Configurator software,
3-10–3-13

- worksheet, 3-2

Configuration mismatch bit, 4-9

CPU compatibility, 1-5

CPU operation, 4-7

D

Data

- default to 0 or hold last state, 3-9 , 3-12

- formats, 4-8–4-12

- quantities for master, 1-1

Default states, configuring, 3-6

Diagnostics

- Addition of Module, 2-3

- Loss of Module, 2-4

Distance between devices, 2-9

E

Electromagnetic noise, 2-10

F

Fanuc I/O Link, 1-1

+5 volt output, 2-7

Forcing I/O, 1-1

Fuse, 1-3 , 2-7

G

Grounding cable, 2-8

H

Hand-held Programmer, 1-1

Hold Last State, 3-9 , 3-12

Humidity specification, 1-5

I

I/O capacity, 1-1

I/O Link Interface Module, 1-2

I/O Link Master Module

- appearance, 1-3

- data transfer, 4-2 , 4-4

- installing, 2-2

- number in PLC, 1-2

- number in rack, 1-3

- operation, 4-1

- rack location, 1-5

- removal, 2-4

Input reference table, 3-3

- configuration, 3-3 , 3-7 , 3-11

Inputs, 4-1

- data formats, 4-8

- default or hold last state, 3-9 , 3-12 , 4-5

- references for slaves, 3-8 , 3-12

- status bits, 4-9

Installation, 2-2

Installation, optical adapter, 2-11

L

LEDs, 1-3 , 1-4 , 2-3

Link active, 4-9
Link operation stops, 4-5
Loss of Module diagnostic, 2-4

M

Module installation, 2-2
Module removal, 2-4

N

Number of I/O points, 1-5

O

Operation, stops, 4-5
Optical adapter, 2-10 , 2-11
Output reference table
 configuration, 3-7 , 3-12
 configuring, 3-3
Output, +5 volt, 2-11
Outputs, 4-1
 data formats, 4-11
 default or hold last state, 3-9 , 3-12 , 4-5
Overrides, 1-1
Overview, of configuration steps, 3-1–3-6

P

Pin assignments, 2-7
PLC CPU operation, 4-7
Port, 1-3 , 1-4
Port pin assignments, 2-7
Power, cycle to each device, 4-6
Power supply, PLC, 1-3
Problem correction, 4-6

Programming, 4-7

R

Removal, 2-4
Restart I/O Link, 4-12
Restart operation, 4-6
Restart pushbutton, 1-3 , 1-4

S

Shock specification, 1-5
Slave devices, configuring, 3-4
Slaves
 configuring, 3-5 , 3-8 , 3-12–3-13
 input references, 3-8 , 3-12
 lose power, 4-5
 missing, 4-9
 number of, 1-1
 type, 1-1 , 1-5 , 3-8 , 3-12
Specifications, 1-5
Status information, 3-3
Stop mode, 4-5
System overview, 1-1

T

Temperature specification, 1-5
Twisted pair wires, 2-8

V

Vibration specification, 1-5

W

Worksheet, configuration, 3-2