

Modicon 984 Student Reference Guide


GJ-0001-000 Rev. D

**AEG SCHNEIDER
AUTOMATION**
Modicon • Square D • Telemecanique

MODICON

GJ-0001-000 Rev. D

984 Student Reference Guide



Preface

The information in this document is subject to change without notice and should not be construed as a commitment by MODICON Inc., Industrial Automation Systems Group. MODICON Inc. assumes no responsibility for any errors that may appear in this document. No part of this document may be reproduced in any form without the express written permission of MODICON Inc., Industrial Automation Systems Group. All rights reserved.

The following are trademarks of MODICON Inc.:

| | | |
|-------------|-----|------|
| MODICON | 084 | 184 |
| Micro 84 | 284 | 884 |
| Compact 984 | 484 | 984 |
| Modbus | 584 | P180 |
| Modvue | 384 | P190 |
| Modway | | |

IBM is a registered trademark of International Business Machines, Inc.;
IBM PC is a trademark of International Business Machines, Inc.

Copyright 1992, MODICON Inc.

Printed in U. S. A.

Table of Chapters

| | |
|-------------------|--|
| Chapter 1 | Introduction to Programmable Control |
| Chapter 2 | 984 Controller and Remote I/O Processor Models |
| Chapter 3 | 800 Series Local and Remote I/O |
| Chapter 4 | 200 and 500 Series Remote I/O |
| Chapter 5 | Input and Output Module Specifications |
| Chapter 6 | System Level Configuration, Planning and Cabling |
| Chapter 7 | 984 Man-Machine Interfaces |
| Chapter 8 | Software System Configuration |
| Chapter 9 | Programming Ladder Logic |
| Chapter 10 | Load, Record, Verify |
| Chapter 11 | Ladder Lister |
| Chapter 12 | Trouble shooting |
| Chapter 13 | Compact 984 and A120 I/O |
| Appendix A | Glossary |
| Appendix B | Error Codes |

Table of Contents

| | |
|---|-------------|
| Title | |
| Preface | i |
| Table of Chapters | iii |
| Table of Contents | v |
| | |
| Chapter 1 Introduction To Programmable Control | 1-1 |
| | |
| Numbering Systems | 1-2 |
| Decimal | 1-2 |
| Binary | 1-3 |
| Binary Coded Decimal (BCD) | 1-3 |
| Hexadecimal (Hex) | 1-4 |
| Number System Examples | 1-4 |
| Controller Basics | 1-6 |
| Processes Under Control | 1-8 |
| Input/Sensing Devices | 1-9 |
| Input Modules | 1-10 |
| Controller | 1-13 |
| Output Modules | 1-14 |
| Output/Working Devices | 1-17 |
| Man-Machine Interface | 1-18 |
| Introduction To Data Communications | 1-19 |
| Information Structure | 1-19 |
| Serial Communications | 1-20 |
| Modulated Serial Communication | 1-21 |
| RS-232-C | 1-22 |
| Parallel Communications | 1-23 |
| | |
| Chapter 2 984 Controller and Remote I/O Processor Models | 2-1 |
| | |
| 984-380,984-381 and 984-385 | 2-2 |
| Features | 2-2 |
| Controller Status Indicators | 2-3 |
| Controller Cartridges | 2-4 |
| MODBUS DIP Switch Configuration | 2-5 |
| 984-480 and 984-485 | 2-6 |
| Features | 2-6 |
| Controller Status Indicators | 2-7 |
| Controller Cartridges | 2-8 |
| MODBUS DIP Switch Configuration | 2-9 |
| 984-680 and 984-685 | 2-10 |
| Features | 2-10 |
| Controller Status Indicators | 2-11 |
| Controller Cartridges | 2-12 |
| MODBUS DIP Switch Configuration | 2-13 |
| Remote I/O Processor | 2-14 |

| | |
|--|-------------|
| 984-780 and 984-785 | 2-16 |
| Features | 2-16 |
| Controller Status Indicators | 2-17 |
| Controller Cartridges | 2-18 |
| MODBUS DIP Switch Configuration | 2-19 |
| Remote I/O Processors | 2-20 |
| Controller Housings for 984 Slot Mount Series | 2-22 |
| Back plane Connectors | 2-23 |
| Compact 984 - 120, 130 and 145 | 2-24 |
| Features | 2-24 |
| Controller Status Indicators | 2-25 |
| Back plane for the Compact 984 | 2-26 |
| The DTA Primary Back plane | 2-26 |
| DTA 201 and DTA 202 Secondary Back planes | 2-27 |
| Controller Option Modules for 984 Slot Mount Series | 2-28 |
| Hot-Standby Processor | 2-28 |
| 984X 2-30 | |
| Features | 2-30 |
| Power Supply | 2-31 |
| Central Processing Unit | 2-32 |
| Multi-Option Processor | 2-33 |
| 984A 2-34 | |
| Features | 2-34 |
| Power Supplies | 2-35 |
| Central Processing Unit | 2-36 |
| Memory Module | 2-36 |
| Remote I/O Processors | 2-38 |
| Communications Processor | 2-40 |
| 984B 2-42 | |
| Features | 2-42 |
| Power Supplies | 2-43 |
| Central Processing Unit | 2-44 |
| Memory Module | 2-44 |
| Remote I/O Processors | 2-46 |
| Communications Processor | 2-48 |
| Controller Chassis for 984 A, B, and X | 2-49 |
| Controller Option Modules For 984 A, B, and X | 2-50 |
| Hot-Standby Processor | 2-50 |
| MODBUS II Communications Processor | 2-52 |
| Dual RS-232 Modem | 2-54 |
| Integrated Control Processor | 2-56 |
| Resident Instruction Sets for 984 Controllers | 2-58 |
| Standard Set for all 984 Controllers | 2-58 |
| Enhanced Set for 984 Slot Mount Series | 2-59 |
| Loadable Options for All Controllers | 2-60 |
| 984 System Capabilities Table | 2-61 |

Chapter 3 Local and Remote 800 Series I/O 3-1

| | |
|---|-------------|
| I/O Drop Overview | 3-2 |
| Local I/O | 3-2 |
| Remote I/O | 3-3 |
| Components Common to Local and Remote Drops | 3-5 |
| Controller Housings and Chassis | 3-5 |
| Secondary Housings | 3-7 |
| Auxiliary Power Supplies | 3-8 |
| Cables | 3-16 |
| Local Drop Configurations | 3-17 |
| 984-380, 381, 385 Controller | 3-17 |
| 984-480, 485 Controller | 3-18 |
| 984-680, 685 Controller | 3-19 |
| 984-780, 785 Controller | 3-20 |
| 984X Controller | 3-21 |
| Local Drop Size Summary Matrix | 3-22 |
| Remote Drop Hardware for S908/S929 and S901 I/O Processors | 3-23 |
| 800 Series Remote I/O Drops | 3-23 |
| Remote I/O Interfaces for S908/929 Systems | 3-25 |
| J890/892 Interface | 3-30 |
| 800 Series Remote I/O with the S901 I/O Processor | 3-35 |
| J810/812 Interface | 3-35 |
| D908 Distributed Control Drop with 984-680 | 3-41 |
| Distributed Control Drop | 3-42 |
| Remote Drop Configurations for S908/S929 I/O Processors | 3-44 |
| 800 Series Drop | 3-44 |
| S908/S929 Drop Size Summary Matrix | 3-46 |

Chapter 4 200 and 500 Series Remote I/O 4-1

| | |
|--|-------------|
| P451/P453 Interface using 200 series I/O | 4-2 |
| P451 Interface Module | 4-4 |
| P453 Interface Module | 4-7 |
| P453 Power Supply/Interface for the S908/S929 I/O Processor | 4-11 |
| P453 Power Supply/ Interface for the S901 I/O Processor | 4-15 |
| Auxiliary Power Supplies | 4-21 |
| Cables | 4-22 |
| 200 Series I/O Drop - Summary | 4-24 |
| P451/P453 Interface using 500 Series I/O | 4-25 |
| 500 Series I/O Housings | 4-26 |
| 500 Series Word/Byte Organization | 4-27 |
| J540 Adapter | 4-29 |
| Interface Connections | 4-30 |
| Cables | 4-32 |
| 500 Series I/O Drop - Summary | 4-34 |

Chapter 5 Input and Output Module Specifications 5-1

| | |
|---|-------------|
| 800 Series Input/Output Module Overview | 5-2 |
| I/O Terminal Connectors | 5-3 |
| I/O Module Keying System | 5-4 |
| Input Module Characteristics and Typical Set-up | 5-6 |
| Output Module Characteristics and Set-up | 5-14 |
| Input/Output Module Specifications | 5-22 |
| 800 Series | 5-22 |
| 200 Series | 5-26 |
| 500 Series | 5-28 |
| A120 (Compact 984) Series I/O Modules | 5-30 |
| DEP 208 Discrete Input Module | 5-31 |
| LED's | 5-31 |
| DEP 208 Characteristics | 5-32 |
| DEP 209 Discrete Input Module | 5-33 |
| LED's | 5-33 |
| DEP 209 Characteristics | 5-34 |
| DEP 216 Discrete Input Module | 5-35 |
| LED's | 5-35 |
| DEP 216 Characteristics | 5-36 |
| DEO 216 Discrete Input Module | 5-37 |
| LED's | 5-37 |
| DEO 216 Characteristics | 5-38 |
| DEP 220 Discrete Input Module | 5-39 |
| LED's | 5-39 |
| DEP 220 Characteristics | 5-40 |
| DAP 204 Relay Output Module | 5-41 |
| LED's | 5-41 |
| DAP 204 Characteristics | 5-43 |
| DAP 208 Relay Output Module | 5-45 |
| LED's | 5-45 |
| DAP 208 Characteristics | 5-47 |
| DAP 209 Discrete Output Module | 5-49 |
| LED's | 5-49 |
| DAP 209 Characteristics | 5-50 |
| DAP 216 Discrete Output Module | 5-51 |
| LED's | 5-51 |
| Resetting the Module After an Overload or Short Circuit | 5-52 |
| Protecting the Module from Inductive Back EMF | 5-53 |
| DAP 216 Characteristics | 5-54 |
| DAP 212 Combined I/O Module | 5-55 |
| LEDs | 5-55 |
| DAP 212 Characteristics | 5-57 |
| ADU 204 Analog Input Module | 5-59 |
| LED | 5-60 |
| Noise Suppression DIP Switch | 5-60 |
| Field Wiring | 5-61 |
| Calibrating the Analog Input Channels | 5-61 |
| ADU 204 Characteristics | 5-64 |
| ADU 205 Analog Input Module | 5-65 |
| LED | 5-65 |

| | |
|--|-------------|
| DIP Switch Settings | 5-66 |
| Field Wiring | 5-66 |
| Calibrating the Analog Input Channels | 5-68 |
| ADU 205 Characteristics | 5-70 |
| DAU 202 Analog Output Module | 5-71 |
| LEDs | 5-71 |
| Field Wiring | 5-72 |
| Calibrating the Analog Output Channels | 5-73 |
| DAU 202 Characteristics | 5-75 |

Chapter 6 System Level Configuration, Planning, and Cabling 6-1

| | |
|---|-------------|
| System Cable Topologies | 6-2 |
| Standard Configurations | 6-2 |
| Hot Standby Configurations | 6-5 |
| Summary Of Legal Remote I/O Configurations | 6-8 |
| Illegal Remote I/O Configurations | 6-9 |
| Standard Distributed Control Configurations | 6-10 |
| Hot Standby Distributed Control Configurations | 6-13 |
| Summary of Distributed Configurations | 6-16 |
| Illegal Distributed I/O Configurations | 6-18 |
| Controller Selection | 6-19 |
| Controller Memory Usage | 6-19 |
| Controller Selection Considerations | 6-21 |
| 984 System Capabilities Tables | 6-22 |
| 984 Installation Planning | 6-24 |
| Controller Location | 6-24 |
| Power Sources | 6-24 |
| 984 Environmental Considerations | 6-26 |
| Space Requirements | 6-26 |
| Panel Enclosures | 6-28 |
| 984 PLC Mounting | 6-31 |
| Grounding and Shielding | 6-34 |
| Cable Installation and Planning | 6-38 |
| Cabling Requirements | 6-38 |
| Using a Cable Diagram | 6-40 |
| Cables, Taps, Splitters and Termination Components | 6-44 |
| Remote I/O Cable Selection | 6-44 |
| Cable Connectors and Terminators | 6-48 |
| Cable Fabrication | 6-50 |
| Recommended Tools | 6-50 |

| | |
|---|-------------|
| Chapter 7 984 Man-Machine Interfaces | 7-1 |
| P190 Programmer | 7-3 |
| General Characteristics | 7-3 |
| Front Panel | 7-4 |
| Rear Panel | 7-6 |
| Cabling | 7-9 |
| Tapes | 7-13 |
| Personal Computer | 7-16 |
| Features | 7-16 |
| Specifications | 7-16 |
| Cabling | 7-17 |
| Keyboard | 7-18 |
| Floppy Disks/Part Numbers | 7-19 |
| Back Up Disks | 7-20 |
| Preparing to use Modicon Executive Software | 7-20 |
| 964/965 Hand-Held Interfaces | 7-21 |
| Features | 7-21 |
| Operations | 7-21 |
| Cabling | 7-22 |
| Keyboard | 7-23 |
| Software Label Keys | 7-24 |
| Alphanumeric Keys | 7-24 |
| Display Select Keys | 7-24 |
| Control Keys | 7-25 |
| Reference Operation Keys | 7-25 |
| ON/OFF Keys | 7-25 |
| P964 Menu | 7-26 |
| P964 Menu Selection Descriptions | 7-27 |
| P965 Menus | 7-28 |
| 965 Menu Selection Descriptions | 7-29 |
| P965 MDAP Menu Selection Descriptions | 7-31 |
| Unsupported Communication Parameters | 7-32 |
| DEC PDP-11 and VAX | 7-34 |
| 984/DEC PDP-11 | 7-34 |
| 984/DEC VAX | 7-34 |

Chapter 8 Software System Configuration 8-1

| | |
|--|------------|
| P190/Personal Computer Characteristics | 8-2 |
| Modicon's P190 Emulation Software for IBM Computers | 8-2 |
| Program Selection | 8-2 |
| P190/Personal Computer Softkeys | 8-3 |
| P190/Personal Computer Keyboard Comparison | 8-4 |
| Configuration and Traffic Copping Software Overview | 8-5 |
| System Operation | 8-6 |
| Dim Awareness and Battery Installation | 8-6 |
| Configuration Program Features | 8-7 |
| Configuration Operations | 8-7 |
| Software Media and Part Numbers | 8-8 |
| Screen Configuration with Softkey Menu | 8-9 |

| | | |
|---|-------------|-------------|
| Use of Reference Numbers | 8-11 | |
| State RAM | 8-12 | |
| Segmentation and Scheduling of Logic Networks | | 8-14 |
| Move Segment Procedure | 8-15 | |
| Configuration Procedure | 8-16 | |
| Configuration Example | 8-18 | |
| Configuration Menu Tree <984 CONFIG> | | 8-34 |
| Configuration Menu Tree <984 ATTACH> | | 8-35 |
| ATTACH UNIT # | 8-37 | |
| Traffic Cop Program Features | 8-38 | |
| P190/Personal Computer Software | | 8-38 |
| Traffic Cop Procedure | 8-40 | |
| S908 Traffic Cop Example | 8-42 | |
| Traffic Copping a Standard Drop | 8-42 | |
| Traffic Copping a Distributed Control Drop | | 8-54 |
| Traffic Copping a J290/J291 I/O Drop | 8-56 | |
| S908 Traffic Cop Menu Tree | 8-62 | |
| ATTACH UNIT # | 8-63 | |
| RELEASE 984 | 8-63 | |
| S901 Traffic Cop Example | 8-64 | |
| Traffic Copping a Standard Drop | 8-66 | |
| S901 Traffic Cop Menu Tree | 8-72 | |
| ATTACH UNIT # | 8-73 | |
| RELEASE 984 | 8-73 | |

Chapter 9 Programming Ladder Logic 9-1

| | | |
|--|-------------|-----|
| Programmer Tape/disc | 9-2 | |
| Features | 9-2 | |
| Functions | 9-2 | |
| Operations | 9-2 | |
| Battery Backup | 9-3 | |
| Pre-Programming Information | 9-4 | |
| Overview | 9-4 | |
| 984 Set Up | 9-4 | |
| Reference Numbers | 9-6 | |
| OXXXX: Coil or Discrete Output | | 9-6 |
| 1XXXX: Discrete Input | 9-6 | |
| 3XXXX: Input Register | 9-6 | |
| 4XXXX: Output Register or Holding Register | | 9-6 |
| 6XXXX: Extended Memory Register | 1-6 | |
| 984 Ladder Logic Elements | 9-7 | |
| Network Structure | 9-8 | |
| Logic Solving Sequence | 9-9 | |
| Element Positional Relationships | 9-10 | |
| Programming Information | 9-12 | |
| Program Tape Screens | 9-12 | |
| Alternate or Reference Screen | 9-14 | |
| Main Loop Sequence | 9-15 | |
| Background Diagnostics | 9-27 | |
| Hints to Minimize Scan Time | 9-27 | |

| | |
|---|--------------|
| P190 Keyboard Functions | 9-28 |
| Discrete Traffic Cop Numbers | 9-30 |
| Programming Elements | 9-31 |
| Relay Contacts | 9-31 |
| Transitional Contacts | 9-33 |
| Vertical and Horizontal Shorts | 9-34 |
| Coils | 9-35 |
| Duplication of Programmed Output Reference | 9-37 |
| Programming Functions | 9-38 |
| Timers | 9-38 |
| Counters | 9-40 |
| Calculates | 9-42 |
| Data Transfer (DX) Move Functions | 9-50 |
| Extended Memory Write | 9-71 |
| Subroutine Functions – Models 984 - x8x Only | 9-76 |
| Data Transfer (DX) Matrix Functions Overview | 9-81 |
| Special Instructions | 9-99 |
| Simple ASCII | 9-106 |
| Simple ASCII Overview | 9-106 |
| Simple ASCII Configuration | 9-107 |
| Simple ASCII Screen | 9-108 |
| Simple ASCII Message | 9-109 |
| Editing | 9-114 |
| Function Blocks | 9-114 |
| Networks | 9-114 |
| 984 Optimize vs Run Modes | 9-118 |
| Programming Menu Tree | 9-119 |
| 984 Programmer Tape (Reset Level) | 9-119 |
| 984 Programmer Tape (Exit Level) | 9-120 |
| 984 Programmer Tape (Exit Level) | 9-121 |
| | |
| Chapter 10 Load, Record, Verify | 10-1 |
| | |
| LRV Disk And Tape Loader Tape | 10-3 |
| Features | 10-3 |
| LRV Examples | 10-4 |
| LRV Menu Tree | 10-12 |
| | |
| Chapter 11 Ladder Lister | 11-1 |
| | |
| Ladder Lister Floppy Disk and Utility Tape | 11-2 |
| Features | 11-2 |
| Ladder Lister Examples | 11-2 |
| Ladder Lister Menu Tree | 11-8 |

Chapter 12 Trouble shooting 12-1

| | |
|---|--------------|
| Introduction | 12-3 |
| Tools, Equipment, and the Trouble shooting Process | 12-4 |
| Types of Faults | 12-4 |
| Isolating Faults | 12-5 |
| Flow Charts | 1-6 |
| Monitoring System Status | 12-7 |
| Trouble shooting Flow Chart | 12-8 |
| Flow Chart Procedures | 12-10 |
| The 984/S908 STAT Block | 12-16 |
| The S908 STAT Block | 12-16 |
| System Mainframe Status | 12-20 |
| I/O Module Health Status | 12-23 |
| Drop Communication Status | 12-25 |
| STAT Block Applications | 12-32 |
| I/O Module Health Status Application | 12-32 |
| Communication Status | 12-35 |
| P190 or Personal Computer | |
| Direct Access to S908 STAT Data | 12-38 |
| Procedure for Retrieving 984 | |
| Register Information Using the P190 | 12-38 |
| P965 Direct Access to S908 STAT Data | 12-40 |
| Procedure for Retrieving 984 Register | |
| Information Using the P965 | 12-40 |
| The 984/S901 STAT Block | 12-42 |
| The S901 STAT Block | 12-42 |
| Controller Status | 12-46 |
| I/O Module Health Status | 12-49 |
| Remote I/O Communication Status | 12-50 |
| P190 or Personal Computer Direct | |
| Access to S901 STAT Data | 12-51 |
| Procedure for Retrieving 984 Register Information Using the | |
| P190 | 12-53 |
| P965 Direct Access to S901 STAT Data | 12-54 |
| Procedure for Retrieving 984 Register Information Using the | |
| P965 | 12-55 |
| Replacement Parts and Technical Support | 12-56 |

Chapter Thirteen Compact 984 Controllers and A120 I/O 13-1

| | |
|---|-------------|
| General Overview | 13-2 |
| Special Features of the Compact 984 | 13-4 |
| CPU User Memory Options | 13-4 |
| Auxiliary Memory Upload-Download Capabilities | 13-6 |
| Slide Switches | 13-7 |
| Modbus Communication Interface | 13-7 |
| LED Indicators | 13-8 |
| A120 I/O Support | 13-9 |
| Power Supplies | 13-11 |

| | | |
|---|--------------------|--------------|
| I/O Housings and Drop Configurations | 13-13 | |
| DTA Back planes | 13-13 | |
| Drop Layout | 13-15 | |
| Modbus Plus Hardware on the Compact | 984-145 | 13-18 |
| The MB Plus LED | 13-19 | |
| The comm parameter slide switch | 13-19 | |
| Modbus Plus Addressing DIP Switch | 13-19 | |
| | | |
| Appendix A | Glossary | |
| | | |
| Appendix B | Error Codes | |